

INSTALLATION INSTRUCTIONS

2021-2025 Tahoe/Yukon/Suburban Console Safe w/ 3 Digit Combo Lock Safe #424-01-A

Please read and fill out the enclosed warranty registration card or register online at <https://tuffyprompts.com/help/warranty-information/warranty-registration/> to activate your warranty.

PARTS CHECKLIST



424-01-A Console Safe

TOOL CHECKLIST

- 10mm SOCKET AND DRIVER

PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

- 1) Verify your vehicle is a 2021-2025 Tahoe, Yukon, or Suburban
- 2) Remove all contents from the shipping box and confirm that you have the correct safe.
- 3) Open the factory Console lid and remove all the contents including the pad at the bottom if applicable.
- 4) Remove the the (2) factory OEM bolts using the 10mm Socket and driver, and place them to the side.
- 5) With the lid open and the legs extended, place the safe into the console with the lock towards the front of the vehicle as shown in Figure 1.
- 6) Align the holes on the feet of the safe with Factory holes in the console, and re-insert the factory OEM bolts.
- 7) Tighten the factory OEM bolts using the 10mm Socket and driver.
- 8) Reinstall the mat and the contents. Make sure you keep contents below the Hinge and locking mechanisms to avoid any entanglement with these features.

FRONT OF
VEHICLE



FIGURE 1

INSTALLATION INSTRUCTIONS

2021-2025 Tahoe/Yukon/Suburban Console Safe w/ 3 Digit Combo Lock Console Safe #424-01-A

Please read and fill out the enclosed warranty registration card or register online at <https://tuffypromducts.com/help/warranty-information/warranty-registration/> to activate your warranty.

A. The combination is factory set at
>>0-0-0<<

B. Combination must be on opening number prior to resetting.

C. On the underside outer edge of the lock there is a hole for the code reset button. Rotate the face of cam until the code reset button comes into view.

D. Push the code reset button in with a paper clip and keep it pushed in!

E. Set your personal combination by turning the dials to the desired combination - starting with the dial marked '1', and moving to '2', '3', and then '4'.

F. Release the code reset button and your combination is set.

G. To lock, rotate lock to "locked" position. Rotate one or more dials after lock is closed.

H. To open the lock, turn dials to your personal combination.



**CODE RESET
BUTTON**

NOTE: If you desire, the Combi-Cam can be installed such that it is non-resettable.

Directions:

Take off the screw to the cam and remove the cam and the "stop cam".

Rotate the cylinder 180 degrees and then put the "stop cam" and the cam back on.