

VOLANT AIR INTAKE SYSTEMS

PART NO.: 16857152


INSTALLATION INSTRUCTIONS

WWW.VOLANTPERFORMANCE.COM


TECH SUPPORT: (909) 476-7225

16857152 PARTS LIST				
1	VOLANT FILTER BOX	1	3 1/2" X 2 1/2" SLEEVE	
1	VOLANT FILTER BOX LID	1	3" X 2" SLEEVE	1
1	VOLANT AIR DUCT	2	1/4"-20 BOLTS	1
1	VOLANT RAM AIR SCOOP	3	1/4" WASHERS	2
1	RAM FILTER W/CLAMP	2	1/4" LOCK WASHERS	2
2	#048 CLAMPS	4	1/4"-20 TRUSS HEAD SCREWS	1
2	#056 CLAMPS	4	1/4" RUBBER WASHERS	

TOP VIEW



FRONT VIEW



NOTE:

1. ATTACH THE 3" X 2" SLEEVE TO THE FILTER BOX WITH A #048 CLAMP. DO NOT TIGHTEN.
2. BEFORE ATTACHING THE ACCESSORY RAM AIR SCOOP, REMOVE THE PLASTIC INSERT FROM THE AIR VENT LOCATED NEXT TO THE LOWER LIGHT HOUSING ON THE DRIVER'S SIDE.
3. ATTACH THE BR26852 BRACKET TO THE RAM AIR SCOOP WITH THE HARDWARE PROVIDED.
4. ATTACH THE RAM AIR SCOOP TO THE 3" X 2" SLEEVE WITH A #048 CLAMP. DO NOT TIGHTEN. ATTACH THE OTHER END OF THE BRACKET TO THE EXISTING HOLE WHERE THE STOCK SYSTEM WAS FASTENED WITH A STOCK BOLT.
5. ADJUST ALL PARTS AND HARDWARE THEN TIGHTEN BOLTS & CLAMPS.

ACCESSORY
RAM AIR SCOOP

