

VOLANT AIR INTAKE SYSTEMS




PART NO.: 16857153

INSTALLATION INSTRUCTIONS

WWW.VOLANTPERFORMANCE.COM

TECH SUPPORT: (909) 476-7225

16857153 PARTS LIST					
1	VOLANT FILTER BOX	1	3 1/2" X 2 1/2" SLEEVE	1	BR19846C BRACKET (SHORT)
1	VOLANT FILTER BOX LID	1	3" X 2" SLEEVE	1	BR26847 BRACKET (LONG)
1	VOLANT AIR DUCT	3	1/4"-20 BOLTS	2	1/2" RUBBER GROMMET
1	VOLANT RAM AIR SCOOP	5	1/4" WASHERS	2	1/2" STRAIGHT FITTING
1	RAM FILTER W/CLAMP	3	1/4" LOCK WASHERS	1	1/2" X 2" BREATHER HOSE
2	#048 CLAMPS	4	1/4"-20 TRUSS HEAD SCREWS		
2	#056 CLAMPS	4	1/4" RUBBER WASHERS		



NOTE: REMOVE THE RADIATOR PROTECTOR SIDE FLAP WITH A FLAT HEAD SCREWDRIVER. ATTACH THE VOLANT BRACKET TO THE EXISTING UPPER BOLT HOLE FOR THE RADIATOR PROTECTOR SIDE FLAP. THEN ATTACH OTHER END OF BRACKET TO THE VOLANT RAM AIR SCOOP.