
SYTHE TOUS TRUCTIONS LATION INSTRUCTIONS INSTRUCTIONS INSTRUCTIONS INSTRUCTIONS INSTRUCTIONS AIR INTAKE SYSTEMS 99-02 24 VALVE TACOMA

WWW.VOLANTPERFORMANCE.COM TECH SUPPORT: (909) 476-7225

വ വ $_{\text{N}}$ N 5/8″ 5/8/ RAM FILTER W/CLAMP FILTER BOX LID FILTER BOX TOYOTA 99-02 24 VALVE TACOMA 1/4" TRUSS HEAD SCREWS 14 1/2" STAINLESS STEEL SCREWS 1/4" RUBBER WASHERS #048 CLAMPS VOLANT AIR DUCT THICK "O" RING 2 1/2" SLEEVE STRAIGHT FITTING X 5" VOLANT HOSE 16" VULANT BREATHER TRIM W/RUBBER SPONGE **HDSE**

REMOVE THE 5/8" STOCK HOSE FROM THE VALVE COVER AND REPLACE IT WITH THE 5/8" X 5" VOLANT HOSE, USE THE 5/8" STRAIGHT FITTING TO ATTACH THE REMAINING END OF THE VOLANT HOSE TO THE 5/8" STOCK HOSE, CONNECT THE OTHER END OF THE STOCK HOSE TO THE VOLANT DUCT.



STOCK BOLT ATTACHES TO PREEXISTING LOCATION OF STOCK FILTER BOX

STOCK BOLT

SIDE VIEW