Revised: 6 /9/05

PRO COMP SUSPENSION, Inc. Chula Vista, CA USA

Ph:(619) 216-1444 ● Fax:(619) 216-1474 ● E-Mail: tech@explorerprocomp.com ● Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS:

Part # 55415
Jeep Wrangler TJ 1.5
Spacer Kit

⇒ **PLEASE READ ALL INSTRUCTIONS FROM START TO FINISH BEFORE YOU BEGIN INSTALLATION.**

Front Disassembly:

1) Block rear tires and raise front of vehicle with floor jack or other suitable means.
2) Support chassis with jack stands behind front lower control arm mounts.
3) Remove wheels, spring retaining clips and front shocks.
4) Lower front axle and remove coils.
5) Remove bump stops by pulling down on rubber piece. This will access bolt that retains bump stop mounting cup.
6) Remove cup and rubber spring pad at the top of spring tower.

Front Assembly:

1) Slide aluminum spacer **#4001** onto bump stop mount.
2) Install spring pad below spacer.
3) Reinstall bump stop cup and rubber bump stop.
4) Install coils, shocks, coil retaining clips and tires.
5) Lower vehicle to ground.

Rear Disassembly:

1) Block front tires and raise rear of vehicle. Support chassis with jack stands in front of rear control arm mounts.
2) Remove tires.
3) Remove lower shock bolts and lower rear axle.

Rear Assembly:

1) Install aluminum spacer **#4004** on spring pad located on rear axle tube.
2) Install rear coils and raise axle to install lower shock bolts.
3) Install tires and lower to ground.
4) Check all hardware for tightness.