T-REX Grilles
Corona, California www.trexbillet.com

55947
2011 TOYOTA
4RUNNER

# 2010 TOYOTA 4RUNNER

## Upper Class Bumper Grille

**TOOLS REQUIRED:**
Socket & Ratchet Set
Flat/Phillips Screwdrivers

**PARTS LIST**
(4) 1/2" L-Brackets
(4) 6/32" Nylon Lock Nuts

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.**

### Step 1

**Open the hood. Use a small flat screwdriver to remove the 13 plastic pop clips on the radiator coverby pushing in on the center part of the pop clips (Fig 1). Remove the radiator cover. Take the mesh grille and insert it into the factory bumper opening. Reach down behind the mesh grille through the area where you removed the radiator cover and locate the threaded studs on the backside of the mesh grille. Place a 1/2" L-bracket on each stud making sure it latches around the plastic bars in the factory bumper opening and install a 6/32" nylon lock on top of the bracket, tighten (Fig3). Repeat this to all three mesh griles. Reinstall the radiator cover. Installation complete.**

Fig 1

Fig 2