



**Crown Automotive Sales Co., Inc.**  
**TJ Dash Tray Installation Instructions**  
**P/N: DT1000**



Kit Contents:

- 1 – Dash Tray
- 2 – Self-Tapping Screws

1. Remove the rubber insert from the top of the dash panel (See Figure 1). Clean the dash panel thoroughly.



2. Place the dash tray on top of the dash panel (See Figure 2). Ensure the dash tray is straight and affix the tray to the dash panel using the supplied self-tapping screws.



3. Trim the rubber insert until it fits snug in the large pocket in the dash tray.

**Note:** Use a UV protective cleaning agent frequently to help prevent the tray from sun fading.

*While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.*