

## **FRONT RUNNER**

# ROOF RACK ACCESSORY MOUNTING BRACKET



RRAC158





#### **READ ME!**



Thank you for purchasing a Front Runner Roof Rack Accessory Mounting Bracket.

Before you start, take a moment to familiarize yourself with the Fitting Instructions and the components received.

Refer to Page 2 for a list of all the components, quantities and tools required.

### IMPORTANT WARNING! /!


IT IS CRITICAL THAT ALL FRONT RUNNER PRODUCTS BE PROPERLY AND SECURELY ASSEMBLED AND ATTACHED TO YOUR VEHICLE. IMPROPER ATTACHMENT COULD RESULT IN AN AUTOMOBILE ACCIDENT, AND COULD CAUSE SERIOUS BODILY INJURY OR DEATH. YOU ARE RESPONSIBLE FOR ASSEMBLING AND SECURING ALL FRONT RUNNER PRODUCTS TO YOUR VEHICLE, CHECKING THE ATTACHMENTS PRIOR TO USE, AND PERIODICALLY INSPECTING THE PRODUCTS FOR ADJUSTMENT, WEAR AND DAMAGE. THEREFORE, YOU MUST READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND PRECAUTIONS SUPPLIED WITH YOUR FRONT RUNNER PRODUCT PRIOR TO INSTALLATION OR USE. IF YOU DO NOT UNDERSTAND ALL OF THE INSTRUCTIONS AND CAUTIONS, OR IF YOU HAVE NO MECHANICAL EXPERIENCE AND ARE NOT THOROUGHLY FAMILIAR WITH THE INSTALLATION PROCEDURES, YOU SHOULD HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL INSTALLER OR OTHER QUALIFIED PERSONNEL.


NOTE: Front Runner will not be responsible for any damage caused by the failure to install the product according to these instructions.

Please call us if you have any questions about the installation of this product.

## **1** GET ORGANIZED

IN T	НЕ ВОХ		
1	2 X	Roof Rack Accessory Mounting Bracket	
2	2 X	M8 x 35 Hex Bolt	
3	4 X	M8 x 20 Hex Bolt	
4	4 X	M8 Nyloc Nut	
5	8 X	M8 Nut Cap	
6	2 X	Eye Nut	
7	2 X	M8 x 16 Hex Bolt	
8	2 X	M8 Nylon Washer	
9	4 X	M8 x 16 x 1.6 Flat Washer	
			Ι






#### **FIT AND SECURE**

2.1 1 1 13mm

Secure the Roof Rack Accessory Mounting Bracket (Item 1) to your roof rack using fasteners supplied.


See 2.3 for mounting options.



To transport BULKY cargo, use two pairs of Mounting Bracket.

Secure the Eye Nuts (Item 6) using M8 x 16 Hex Bolts and M8 Nyloc Washer (Items 7 & 8) as shown.

Stratchits (STRA034 or STRA037) can also be used to secure larger items between brackets



Mounting positions.



### **FINISH**

Congratulations! You did it. Take a step back and admire your work!



### **INSTALL OTHER VEHICLE AND RACK ACCESSORIES**

Now's the time to visit your favorite Front Runner Dealer in person or online.

Be sure to tag us. We love to see our gear in action! #FrontRunnerOutfitters #BornToRoam







