
INSTALLATION INSTRUCTIONS 2011/2012 Fiat License Plate Relocator Part # 75-0000

PARTS LIST:

Qty	Description	Qty	Description
1	Mount Bracket	1	8mm x 20mm Hex Bolt
1	License plate X holder	1	8mm Lock Washer
6	6mm x 25mm Hex Bolt	1	8mm Hex Nut
12	6mm Flat Washer	2	8mm Flat Washer
6	6mm lock washers		





PROCEDURE:

- 1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.
- 2. Begin installation by removing License plate & factory holder (if equipped)
- **3.** Once removed begin installation by locating & removing the 2 factory bolts just under the front bumper lip on passenger right side vehicle (**Fig 1**) shows location of factory bolts.
- 4. With these two bolts removed select the Mount Bracket above and secure to the bumper lip with the (2) 6mm x 25mm Hex bolts & (2) 6mm flat washers & (2) 6mm lock washers as seen in (Fig 2). Snug but do not tighten hardware at this time.
- 5. Attach and secure the License plate X holder to the mount bracket you have just installed with the (1) 8mm x 20mm Hex bolt, (2) 8mm flat washers, (1) 8mm lock washer & (1) 8mm Hex nut Note: there are 3 holes for various position for you to choose, when you have selected to which hole you will use tighten all hardware.

- 6. Next, select your License plate and secure it to the Holder with the (4) 6mm x 25mm Hex bolt, (4) 6mm flat washers & (4) 6mm lock washers, from the list of parts above, (Fig 3) shows installation complete.
- 7. Do periodic inspections to the installation to make sure all hardware is secure and tight.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

For gloss black finishes: Mild soap may be used to clean the Sidebar.

