



TOYOTA
FJ CRUISER
2007-2008 V6-4.0L (1GR-FE)

P/N
49-46005

PERFORMANCE EXHAUST

HIGH TUCK
FOR THE
ROCK-CRAWLER
ENTHUSIAST



Features:

- High performance
- 3" mandrel-bent
- 100% 409 SS
- High ground clearance tip
- Factory style band clamps and hangers

Benefits:

- + 133% flow increase
- + 24 lbs x ft torque
- + 20 H.P.

aFepower.com






Installation Instructions for: TOYOTA FJ CRUISER 2007-2008 V6-4.0L (1GR-FE)



49-46005 (409SS) Cat-Back Toyota FJ Cruiser High Clearance



Step 1: (Read Instructions prior to installation) Remove your stock exhaust from the rear of your truck working your way forward. Take caution not to damage the factory isolation mounts as they will be reused. It may be helpful to lubricate the isolation mounts prior to disassembly. **It is recommended to not fully tighten the clamps until the entire system has been installed.**

Step 2: For faster installation spread the pieces of the exhaust along side of your vehicle according to the diagram shown.

Step 3: Rear isolation mount bayonet hole sits below. Remove rear Isolation mount, flip and re-install so bayonet hole sits upward. Install high clearance tailpipe, utilizing the factory isolation mount. Install the over-axle and band clamp utilizing the 2 factory isolation mounts. **Do not tighten band clamp.**

Step 4: With 3" band clamp install mid-pipe/muffler assembly to over-axle.

Step 5: Re-install isolation mounts to mid-pipe. Install and tighten bolts at cat-side. Now tighten all clamps. Your installation is now complete. aFe recommends to re-tighten all parts after 50-100 miles. **Check periodically.**

NOTE:

- aFe recommends that the tailpipe be at least **3/8"-1/2"** away from any body panels to avoid heat related body damage.

Tighten and secure.

Caution: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on our products.**