


# INSTALLATION INSTRUCTIONS

235019/235019-2

2010 DODGE RAM 2500/3500 CREW CAB

## PARTS LIST:

Qty	Description	Qty	Description
1	Driver/Left Sidebar	4	10mm x 35mm Bolts
1	Passenger/Right Sidebar	8	10mm Lock Washers
1	Driver/Left Front Mounting Bracket	8	10mm Flat Washers
1	Passenger/Right Front Mounting Bracket	4	10mm Nuts
1	Driver/Left Rear Mounting Bracket	4	12mm x 50mm Hex Bolts
1	Passenger/Right Rear Mounting Bracket	4	12mm Lock Washers
6	Plastic Retainers	4	12mm Flat Washers
4	10mm x 35mm Bolt & Nut Plates		



Passenger Side Front Mounting Bracket



Passenger Side Rear Mounting Bracket



Driver Side Front Mounting Bracket



Driver Side Rear Mounting Bracket



10mm x 35mm Bolt/10mm Nut Plate (pictured with Plastic Retainer installed for example)

## PROCEDURE:



- 1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**
2. Starting at the passenger side-front of the vehicle, remove the tape covering the factory oval holes in the passenger side inner panel located by the front tire.
3. Next, partially thread a Plastic Retainer onto the threaded end of a Bolt and Nut Plate, **(Fig 1A)**
4. Once you have assembled the Plastic Retainer onto the Bolt and Nut Plate, insert the Bolt and Nut Plate into the factory oval hole. Once the Bolt and Nut Plate is inserted, hold the Bolt end with one hand and tighten the Plastic Retainer with your other hand. **NOTE:** Tighten the Plastic Retainer until it reaches the side panel, **(Figure 1)**.
5. Select the passenger side front Mounting Bracket. Position the Mounting Bracket onto the installed Bolt Plates. Secure it with (1) 10mm Flat Washers, (1) 10mm Lock Washers and (1) 10mm Hex Nuts, **(Figure 2)**. Do not tighten at this time. Rotate the Bolt and Nut plate until the Nut end lines up with the remaining hole in the Mounting Bracket and body. Thread (1) 10mm x 35mm Hex Bolt, (1) 10mm Flat Washer and (1) 10mm Lock Washer into the threaded nut. Snug but do not tighten hardware at this time.
6. Moving to the passenger side rear of the vehicle, remove the tape covering the factory oval hole in the inner body panel. Thread a Plastic Retainer onto the threaded end of a Bolt and Nut Plate, **(Figure 1A)**. Insert the Bolt and Nut Plate into the factory hole. Once the Bolt and Nut Plate is inserted, hold the Bolt end with one hand and tighten the Plastic Retainer with your other hand, **(Figure 3)**. **NOTE:** Tighten the Plastic Retainer until it reaches the side panel.
7. Select the passenger side rear Mounting Bracket. Position the Mounting Bracket onto the installed Bolt and Nut Plate. Secure it with (1) 10mm Flat Washer, (1) 10mm Lock Washer and (1) 10mm Hex Nut, **(Figure 4)**. Do not tighten at this time. Rotate the Bolt and Nut plate until the Nut end lines up with the remaining hole in the Mounting Bracket and body. Thread (1) 10mm x 35mm Hex Bolt, (1) 10mm Flat Washer and (1) 10mm Lock Washer into the threaded nut. Snug but do not tighten hardware at this time.
8. Next, select the passenger sidebar and fasten it to the Mounting Bracket with the included (2) 12mm x 50mm Hex Head Bolt, (2) 12mm Lock Washer, and (2) 12mm Flat Washer. Snug but do not tighten hardware at this time.
9. Level and align Sidebar properly; then tighten all hardware at this time.
10. Repeat steps 2-9 for driver Sidebar.
11. Do periodic inspections to the installation to make sure all hardware is secure and tight.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.



**For stainless steel:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

**For gloss black finishes:** Mild soap may be used to clean the Sidebar.

### **FRONT PASSENGER SIDE**



**REAR PASSENGER SIDE**



**PASSENGER SIDE INSTALLATION PICTURED**

