

INSTALLATION INSTRUCTIONS

⚠️ **WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

APPLICATIONS

Make	Model
Subaru	B9 Tribeca
Subaru	Forester
Subaru	Impreza WRX wagon
Subaru	Legacy wagon
Subaru	Outback wagon (excl Sport)
Subaru	Tribeca

CUSTOM WIRING CONNECTOR



⚠️ WARNING ⚠️ ⚡

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side
Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

WIRING LOCATION GUIDE

PASSENGER CARS (P)

Representative vehicle shown below

- P3 - Behind driver side taillight housing, inside of trunk
- P4 - Behind passenger side taillight housing, inside of trunk



SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

- S4 - Behind passenger side rear access panel
- S8 - Under rear floor panel



NOTICE ⓘ ⓘ

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

Phillips screwdriver

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Open the vehicle tailgate. Locate the vehicle wiring harness for the specific vehicle following step 2.

Step 2

Outback

Remove the cargo nets and carpet from center and left cargo area (A). Remove the black plastic from the center and left cargo area using a pry tool.

Forester

Locate the vehicle wiring connector in the spare tire area on the passenger side under the threshold or the carpet panel near the passenger side interior trim panel. Remove the fasteners securing the trim panel and remove the panel (C).

Tribeca

Remove the cargo nets and roll back the carpet in the rear cargo area. Remove the four plastic fasteners securing the jack compartment (D). The harness will be located under the rear trim panel near the location shown in figure (B).

Step 3

Once you have located the vehicle wiring connector, remove the tape covering the plug. Insert the custom wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place (E).

Outback Only

Insert the 4-flat through the existing hole in the panel (F).

Step 4

Insert the provided 10-amp fuse into the inline fuse holder.

Step 5

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

Step 6

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

