

INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Toyota	Tundra


WIRING LOCATION GUIDE

PICKUP TRUCKS (T)

Representative vehicle shown below

T3 - Behind driver side rear bumper

CUSTOM WIRING HARNESS



NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

Phillips screwdriver
Flat blade screwdriver

⚠ WARNING

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side
Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Open the vehicle hood. Disconnect the negative battery cable and remove the bracket securing the battery. Temporarily reposition the battery slightly towards the engine.

Step 2

Locate the gray plastic connector between the battery and driver side fender. Remove the protective cover and insert the custom wiring harness attached to the fuse holder into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place (A).

Step 3

Route the other end of the wiring harness to the positive side of the battery and attach the ring terminal to the positive side. Reposition the battery to the original location. Secure any loose wires using cable ties provided. Install the 10-amp fuse into the fuse holder.

Step 4

Behind the rear bumper along the passenger side frame rail, locate the vehicle taillight wiring harness connectors (B). The connectors will be similar to those on the custom wiring harness. Remove the protective cover taking care not to damage the locking tabs. Insert the custom wiring harness connector into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.

Step 5

Locate a flat clean surface that is out of the path of spray and debris from the rear wheels and road. Adhere the black converter box using the provided double-sided tape. Failure to mount the box in a protected area can cause loss of warranty, product failure, overheating and potential fire.

Step 6

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties.

Step 7

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

