

56089

CHEVROLET CAMARO

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

7/30/09



English

1. Open the trunk. Remove the floor coverings. On both sides remove the plastic cover on top of the rear taillight by removing three plastic fasteners on each. [A] Remove the vehicles rear scuff panel by removing three plastic wing nuts on each side. [B] Pull back on the felt trunk liner to reveal the rubber grommet leading to the back of the taillights. [C] Pull out the rubber grommet and make a small slit from the outside of the grommet to the center on both sides of the vehicle.
2. On the drivers side route the T-connector end with yellow wire out through the grommet opening to the backside of the taillight. Locate the vehicles taillight wiring harness. The harness will have connectors similar to those on the T-connector harness. [D] Separate the connectors being sure not to damage the alignment tabs. [E] Insert the T-connector end with the yellow wires in-between the separated connectors. Re-seat grommet routing the yellow wire through the slit.
3. Route the T-connector end with the green wire behind the remove scuff panel to the passenger side. Repeat step 2 on the passenger side using the green wire.
4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.
5. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location on the driver side of the trunk.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.