

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Open the vehicle tailgate. Locate the taillight assembly mounting fasteners (A). Starting on the passenger side, remove the four round plastic covers covering the mounting fasteners (B).

Step 2

Using a 7mm socket, carefully remove the screws holding the taillight assembly and rear bumper fascia in place (C). Remove the taillight assembly by gently pulling rearward and out. Take care not to damage the alignment tabs on back (D).

Step 3


Behind the taillight locate the vehicle taillight wiring harness connectors (E). The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (F).

Step 4

Insert the custom wiring harness end with green wire between the separated connectors (F). Make sure the connectors are fully inserted with locking tabs in place.

Step 5

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

Step 6

Route the custom wiring harness end with the yellow wire to the driver side up the opening behind the rear bumper fascia and taillight assembly. When routing the wires be careful to avoid any hot pipes, heat shields, the fuel tank or any other areas that might pinch or break the wire. Repeat steps 1-4 on the driver side using the harness end with the yellow wire.

Step 7

Locate a flat clean surface that is out of the path of spray and debris from the rear wheels and road. Adhere the black converter box using the provided double-sided tape. Failure to mount the box in a protected area can cause loss of warranty, product failure, overheating and potential fire.

Step 8

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

Step 9

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

Step 10

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

