


# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Mitsubishi	Mirage

## CUSTOM WIRING HARNESS



## WIRING LOCATION GUIDE

### PASSENGER CARS (P)

Representative vehicle shown below

**P3** - Behind driver side taillight housing, inside of trunk

**P4** - Behind passenger side taillight housing, inside of trunk



## NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

Panel trim removal tool

## **⚠ WARNING**

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side

Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Access the vehicle wiring harness connectors in the trunk behind the taillight in positions P3 and P4 as shown in the 'Wiring Location Guide'.

## Step 2

Locate the vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

## Step 3

Open the trunk. Remove all trunk floor coverings (A).

## Step 4

Remove the scuff panel by pulling out on the bottom, then up (B).

## Step 5



Starting on the driver side remove the push fasteners from the side trim panel (C).

## Step 6

Pull back on the side trim panel to locate the vehicle taillight wiring harness connectors (D). The connectors will be similar to those on the T-connector harness. Separate the connectors from the taillight housing, taking care not to damage the locking tabs.

## Step 7

Insert the T-connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place (E).

  **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 8

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

## Step 9

Route the T-connector end with the green wire to the passenger side behind the removed scuff panels. Repeat Steps 5-7 on the passenger side using the T-connector end with the green wire. Use the provided cable ties to secure any loose wires.

## Step 10

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape (F).

## Step 11

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

## Step 12

Reinstall all items removed during install and reconnect the negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

