



INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Chevrolet	Camaro

CUSTOM WIRING HARNESS



WIRING LOCATION GUIDE

PASSENGER CARS (P)

Representative vehicle shown below

P3 - Behind driver side taillight housing, inside of trunk

P4 - Behind passenger side taillight housing, inside of trunk



NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

8mm deep-well socket
Ratchet
Panel trim removal tool
Wire stripper
Wire crimper
Cutting tool

⚠ WARNING

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side

Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

Step 2

Open the vehicle trunk to access the taillight fasteners. Remove all trunk floor coverings (A).

Step 3

Remove the four cargo tie-down fasteners securing the scuff panel (B). Remove the scuff panel by using a trim panel removal tool to carefully pry upwards. Take care not to damage the alignment tabs on the back (C).

Step 4

Starting on the driver side, remove all the push pins and fasteners securing the side felt panel (D). Pull back on the side felt panel (E) to locate the three 8mm nuts holding the taillight in place. Remove the three 8mm nuts (F,G).

Step 5







On the outside of the vehicle, above the taillight, locate and remove the three push fasteners from the top trim panel (H).

Step 6

Remove the taillight by carefully pulling straight back (I). Take care not to damage the plastic alignment tabs located on the inside of the trunk holding the taillight in place.

Step 7

On the back of the taillight locate the vehicle taillight wiring harness connectors (J). The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs (K). Set the taillight aside (L).



INSTALLATION / SAFETY INSTRUCTIONS

Step 8

Locate the grommet behind the taillight where the vehicle taillight wiring passes through from inside the cabin to the taillight (M). Remove the grommet and cut a slit large enough to route the custom wiring harness through (N).

Step 9


Route the custom wiring harness end with the yellow wire out through the grommet opening and through the slit in the grommet. Insert the wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place. Reinstall the taillight.

Step 10

Reseat the grommet and use sealant (not provided) to seal the cut in the grommet and around all the wires.

Step 11

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

Step 12

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape.

Step 13

Route the custom wiring harness end with the green wire to the passenger side behind the removed scuff panel. Repeat steps 4-10 on the passenger side using the harness end with the green wire.

Step 14

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

Step 15

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

Step 16

Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

