11187

95-00 CHRYSLER SEBRING 4 DOOR (EXCEPT CONVERTIBLE) / 95-02 DODGE AVENGER 95-02 CHRYSLER SEBRING 2 DOOR (EXCEPT CONVERTIBLE) / 95-02 DODGE STRATUS 2 DOOR ONLY

10/12/2009

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.


DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

| Parts List | | | |
|------------|-----|---------------------|--|
| ITEM | QTY | PART NUMBER | DESCRIPTION |
| 1 | 1 | 7/16-14 x 1 1/2 | CARRIAGE BOLT |
| 2 | 1 | CM-SP7 | .250 x 1.00 x 2.00" SQUARE HOLE SPACER |
| 3 | 1 | 7/16-14 | LARGE HEX FLANGE NUT |
| 4 | 1 | 5/16" | LOCK WASHER |
| 5 | 1 | M8-1.25 x 35 | HEX TAP BOLT |
| 6 | 4 | 3/8" | CONICAL TOOTHED WASHER |
| 7 | 4 | M10 - 1.25 x 40 HEX | HEX BOLT |
| 8 | 1 | CM-438-FW | 7/16 " FISHWIRE TOOL |



INSTALLATION STEPS

FISHWIRE TECHNIQUE
INSERT COILED END OF FISHWIRE TOOL THROUGH
HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL
AND OUT THE ACCESS HOLE PASS COILED
END OF FISHWIRE THROUGH SPACER AND
THREAD BOLT INTO COIL. KINK WIRE
TO KEEP SPACER SEPERATE FROM

TO KEEP SPACER SEPERATE FROM
BOLT AS SHOWN. PULL
FISHWIRE, SPACER, AND
BOLT THROUGH FRAME
AND OUT MOUNTING HOLE,
USE FISHWIRE TO GUIDE
HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT /
SPACER INSIDE FRAME RAIL.
"MOTE SAME YEAR SAME HOUSE THROUGH THE OF FRAME PARKET."

<u>HITCH WEIGHT:</u> 33 LBS. <u>INSTALL TIME</u>

INSTALL NOTES:

PROFESSIONAL: 40 MINUTES

NOVICE (DIY): 80 MINUTES

-DRILLING REQUIRED -FISHWIRE HARDWARE -EXISTING WELDNUTS

- 1. Remove muffler and heat shield. Remove four existing M10 bolts from frame rails, two per side.
- Raise hitch into position and install four M10 bolts (supplied with hitch) as shown.
 (Note: Heat shield attachment on the trunk pan will need to be shifted for hitch clearance.)
- 3. Using hitch as a template, drill one 1/2" hole for forward attachment as shown.
- 4. Fishwire 7/16" carriage bolt and spacer through access hole on the frame rail. Secure with 7/16" flange nut.
- 5. Install M8 fastener into existing weldnut.
- 6. Reinstall muffler. If existing fasteners are damaged, replace with M10 fasteners provided.
- 7. Return heat shield, bolts and frame rail bolts to vehicle owner for reinstallation if hitch is removed.
- 8. Torque M8 fasteners to 25 lb.-ft. Torque M10 fasteners to 38 lb.-ft. Torque 7/16" fasteners to 50 lb.-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.