



**Before returning this product  
to the store of purchase**

**Contact Dee Zee if you experience the following problems:**

- Missing Parts
- Installation Problems/Questions
- Warranty Questions

**1.800.779.2102**

Hours of operation: 8am - 5pm CST, Mon-Friday

Review complete warranty policy and register your product at:

**[www.deezee.com](http://www.deezee.com)**



## Dee Zee Running Board Installation Instructions

*Congratulations on your purchase of a quality Dee Zee product. Dee Zee is recognized as having the highest quality running boards and accessories on the market today. We have earned this reputation by offering our customers a product they can be proud to place on their vehicles. Dee Zee meets all the criteria of manufacturing a custom-fit product which guarantees it to be the easiest product to install.*

**Note:** Please take time to read all of the instructions before beginning this installation.

**Warning!** Please check for wiring or other obstructions before drilling any holes into the vehicle. If it is necessary to drill any holes into the vehicle, Dee Zee recommends putting a sealant or rust inhibitor around all holes drilled into the body of the vehicle.

**Warning!** It is the sole responsibility of the vehicle owner to check for tire clearance.

**Warning!** It is unlawful and dangerous to ride on running boards or side box boards while the vehicle is in motion.

**Cleaning Instructions:** To maintain the bright finish of your Dee Zee running boards, clean with a mild detergent. For our stainless steel products and accessories, the application of a high grade automotive type wax is recommended.

If you should happen to have any questions with this product or you have an installation question, please feel free to call us at:

**1-800-779-8222**

If you would like to find out more information on Dee Zee's products please feel free to visit our website at:

**WWW.DEEZEE.COM**

# DEE ZEE Running Boards


DZ 1030

96-99 Chevy / GMC Full Size 135" WB Van



<b>A</b>  <b>X2</b>	<b>B</b>  <b>X4</b>	<b>C</b>  <b>X2</b>	<b>D</b>  <b>X6</b>	<b>E</b>  <b>X6</b>
<b>M</b> 1/4" x 1"  <b>X12</b>	<b>N</b> 1/4" x 1"  <b>X12</b>	<b>P</b> 1/4" x 3/4"  <b>X42</b>	<b>S</b> 1/4"  <b>X54</b>	<b>T</b> 1/4"  <b>X54</b>

Tools Required:





Outils Nécessaires:





7/16"  
3/8"




3/16"  
1/4"




**1** Place a britetread mudflap (B) onto each end of britetread running board (A). Attach the britetread mudflap (B) to the britetread running board (A) using 1/4 x 3/4" hex head bolt (P), 1/4" flat washer (T), and 1/4" hex nut (S).




**2** Clean the backlip of britetread running board (A) using a clean cloth.




**3** Place foam gasket (C) onto the backlip of britetread running board (A).



**4** Trim foam gasket (C) so that it is flush with the ends of britetread running board (A).



**5** Place britetread running board (A) up to the vehicle.



**6**

**1/4"**

**Drill five 1/4" holes through the backlip of the britetread running board (A) as shown.**

**3/16"**

**7** Secure britetread running board (A) into place by using 1/4 x 3/4" hex head bolts (P), 1/4" flat washers (T), and 1/4" hex nuts (S).

**7/16"**

**S**  
**T**  
**P**  
**A**

**8** Level out the britetread running board (A) and then drill three 3/16" holes through each mudflap on the britetread running board (A). Secure into place using three 1/4 x 1" sheet metal screws (N).

**3/16"**

**3/8"**

**N**


**9**

**D**  
**D**  
**D**

**17 1/2"**  
**50 1/2"**  
**82 1/2"**

Place angle braces (D) in the locations shown to the right.


**D**  
**A**

**10**

Drill two 1/4" holes up through the bottom of britetread running board (A) at each angle brace (D) location, using the holes in angle brace (D) as a guide.



**11**

Secure angle brace (D) to the britetread running board (A) using 1/4 x 1" ribneck carriage head bolts (M), 1/4" flat washers (T), and 1/4" hex nuts (S).

**7/16"****12a**


Place mounting brackets (E) up to the vehicle frame and angle braces (D) as shown. Drill two 1/4" holes through the frame, using the mounting bracket (E) as a guide.

**Note:** Repeat this process for all of the angle brace placements.





**12b****7/16"**

Secure each mounting bracket (E) into place using 1/4 x 3/4" hex head bolts (P), 1/4" flat washers (T), and 1/4" hex nuts (S).

**Note:** Repeat this process for all of the angle brace placements.



- 13** Drill two 1/4" holes through angle brace (D), using mounting brace (E) as a guide. **Note:** Repeat this process for each angle brace (D) location.



- 14** Place 1/4 x 3/4" hex head bolts (P) through mounting bracket (E) and angle brace (D). Secure into place using 1/4" flat washer (T) and 1/4" hex nut (S). **Note:** Repeat this process for each mounting bracket (E) location.

