

# Mud Flap Installation Instructions

## DZ 2805

### (1999 - Current) Ford Superduty Dually Mud Flap F150 / F250 / F350

*Congratulations on your purchase of a quality Dee Zee product. Dee Zee is recognized as having the highest quality running boards and accessories on the market today. We have earned this reputation by offering our customers a product they can be proud to place on their vehicles. Dee Zee meets all the criteria of manufacturing a custom-fit product which guarantees it to be the easiest product to install.*


**TOOLS REQUIRED:**









- 10mm Wrench
- 13mm Wrench
- Phillips Screwdriver
- Regular Screwdriver
- Locking Pliers
- Drill with a set of bits

<b>PARTS LIST:</b>	<b>QTY</b>
Britetread Mud Flaps (A) .....	2
Mounting Brackets (H) .....	2
Hardware Bag .....	1

**INSTRUCTIONS:** Please take time to read all instructions carefully before beginning installation.



**NOTE:** Not responsible for damages to the body of the vehicle if the product is improperly installed.



<b>A</b>  <b>Britetread Mudflap</b> <div style="text-align: right;"><b>2X</b></div>	<b>B</b>  <b>Ratchet Fastener</b> <div style="text-align: right;"><b>2X</b></div>	<b>C</b>  <b>1/4\" Hex Head Bolt</b> <div style="text-align: right;"><b>2X</b></div>	<b>D</b>  <b>1/4\" Washer</b> <div style="text-align: right;"><b>2X</b></div>	<b>E</b>  <b>1/4\" Locknut</b> <div style="text-align: right;"><b>2X</b></div>
<b>F</b>  <b>Sheet Metal Screw</b> <div style="text-align: right;"><b>4X</b></div>	<b>G</b>  <b>Fenderwell Clip</b> <div style="text-align: right;"><b>4X</b></div>	<b>H</b>  <b>Mounting Bracket</b> <div style="text-align: right;"><b>2X</b></div>		


**Step 1**

Using the drawing below as a guide, locate the existing bolt on the rear inner fender well and remove this bolt and nut using a 10mm and 13mm wrench.




## Step 2

Using the drawing below as a guide, place the mounting bracket (H) into place as shown and then replace the existing nut and bolt.



## Step 3



Using the drawing below as a guide, locate and remove the ratchet fasteners in the fender well using a regular screwdriver and locking pliers. Once these have been removed, discard them.



## Step 4


Using the drawing below as a guide, place a fenderwell clip (G) onto the fenderwell lip as shown at each of the locations.

Fender Well Clip (G)




### Step 5

Using the drawing below as a guide, locate the phillips head screw at the bottom of the inside rear fender well and remove it using a phillips head screwdriver. Do not discard it, since it will be used in Step 6 to locate and attach the britetread mudflap to the rear fender well.



### Step 6


Using the drawing below as a guide, place the phillips head screw through the pre-punched hole in the britetread mudflap and into the existing threaded hole in the rear fender well.



### Step 7


Using the drawing to the right as a guide, place sheet metal screw (F) through the britetread mudflap (A) and into the fenderwell clips (G) which were installed in Step 4. Secure into place using a phillips head screwdriver.

Now place a 1/4" hex head bolt (C) through the existing hole as shown in the drawing to the right. The 1/4" hex head bolt (C) will go completely through the britetread mudflap (A) and the mounting bracket (H) installed in Step 2. Secure into place using a 1/4" flat washer (D) and 1/4" locknut (E). Tighten until snug using a 13mm wrench.




### Step 7

Using the drawing below as a guide, drill a 1/4" hole through the britetread mudflap (A) and the plastic of the inner fender well.



### Step 8

Using the drawing below as a guide, place a ratchet fastener (B) through the drilled hole in the britetread mudflap (A) and the plastic of the inner rear fenderwell. Press the ratchet fastener (B) firmly into place.



**Repeat Steps 1 through 8 for the passenger side of the vehicle.**

*\*\*If you should incur any problems with the installation of this product, please feel free to call us at 1-800-779-8222.  
So that we may better serve you when you call, please have the W/O#, SEQUENCE#, and the DATE  
from the labels on the outside of the box.*