



**Before returning this product  
to the store of purchase**

**Contact Dee Zee if you experience the following problems:**

- Missing Parts
- Installation Problems/Questions
- Warranty Questions

**1.800.779.2102**

Hours of operation: 8am - 5pm CST, Mon-Friday

Review complete warranty policy and register your product at:

**[www.deezee.com](http://www.deezee.com)**

# DZ Running Board Installation Instructions

## DZ 3019

### Dodge Ram Pickups '94-Current

*Congratulations on your purchase of a quality Dee Zee product. Dee Zee is recognized as having the highest quality running boards and accessories on the market today. We have earned this reputation by offering our customers a product they can be proud to place on their vehicles. Dee Zee meets all the criteria of manufacturing a custom-fit product which guarantees it to be the easiest product to install.*

**NOTICE:** This product requires the use of sheet metal screws. To use these screws, drill a hole as specified in the instructions. Once the hole has been drilled, tighten the screw firmly into the hole with a wrench. Caution should be taken **not to overtighten** the sheet metal screws.

**INSTRUCTIONS:** Please take time to read all instructions carefully before beginning installation.

**NOTE:** After drilling, Dee Zee recommends putting a sealant or rust inhibitor around all holes drilled into the body panel of the vehicle.

**NOTICE:** With the left and right angle brace, add a flat bar by matching the two holes in each part. Fasten with two 1/4" x 3/4" hex head bolts (J), washers and nuts (N). These L-braces will be used later in the instruction.

#### TOOLS REQUIRED:

Two 7/16" Wrenches

A 3/8" Wrench

A Drill with a set of Bits

A Level


Locking Pliers

A Tape Measure

#### PARTS LIST:

	QTY
Running Boards .....	2
Mudguards .....	2
Channel Braces .....	2
Left & Right Angle Braces .....	2
8 1/2" Flat Bar Braces .....	2
Hardware Bag .....	1


**Warning:** It is the sole responsibility of the vehicle owner to check for tire clearance.



#### STEP 1

Attach a mudguard to the front of each running board with two 1/4" x 3/4" hex head bolts (J), washers and nuts (N).


**BEFORE PROCEEDING:** Take the time to check the rocker panels and wheel wells of your vehicle for protruding bolt heads that may prevent a flush mounting. Remove these bolts and replace or discard after installation.



#### STEP 2


Position the running board to the side of your vehicle so that the back lip of the running board is aligned to the vehicle's rocker panel lip and the mudguard is snug against the trailing edge of the front wheel well.

Level the running board and drill four evenly spaced 1/4" holes through the running board and the rocker panel lip. Attach the running board to the rocker panel lip with four 1/4" x 1" carriage bolts (C), washers and nuts (N).




#### STEP 3

Level the running board and drill three 3/16" holes through the mudguard and wheel well lip. Attach the mudguard to the wheel well lip with three 1/4" x 1" sheet metal screws (E).



#### STEP 4


At approximately 53" from the front of the board, position an L-brace to the sub-body support and the rear of the board. Use the first and third holes in the L-brace as a guide to drill two 1/4" holes through the running board step. Secure in place with 1/4" x 1" carriage bolts (C), washers and nuts (N). Level the running board to the vehicle. Use the holes in the top of the brace as a guide to drill two 3/16" holes through the sub-body support. Attach with two 1/4" x 1" sheet metal screws (E).



#### STEP 5

At approximately 30" back from the front of the running board, position channel brace to the underside of the running board and sub-floor support as shown. Use the holes in the channel brace as a guide to drill two 1/4" holes through the running board step. Secure in place with 1/4" x 1" carriage bolts (C), washers and nuts (N).













Use the hole in the opposite end of the channel brace as a guide to drill one 1/4" hole up through the sub-floor support and attach the channel brace to the sub-floor support using a 1/4" x 3/4" hex head bolt (J), washer and nut (N).



**CLEANING INSTRUCTIONS:** To maintain the bright finish of your Dee Zee aluminum running boards, clean with a mild detergent.

**WARNING:** It is unlawful and dangerous to ride on running boards or side box boards while vehicle is in motion. It is the sole responsibility of the owner to check for tire clearance.

*\*\*If you should incur any problems with the installation of this product, please feel free to call us at 1-800-779-8222. So that we may better serve you when you call, please have the W/O#, SEQUENCE#, and the DATE from the labels on the outside of the box.*

<p>1/4" x 1" Black Sheet Metal Screw PN 97B</p>  <p><b>S</b></p>	<p>1/4" x 1" Sheet Metal Screw PN 97</p>  <p><b>E</b></p>	<p>#10 x 5/8" Phillips Head Screw PN 140</p>  <p><b>P</b></p>	<p>1/4" x 1" Slotted Fillister Head Screw PN 80</p>  <p><b>L</b></p>
<p>1/4" x 1" Slotted Head Bolt PN 86A</p>  <p><b>A</b></p>	<p>1/4" Washer PN 72 &amp; 1/4" Nut PN 71</p>  <p><b>N</b></p>	<p>1/4" x 1" Black Carriage Bolt PN 87B</p>  <p><b>T</b></p>	<p>1/4" x 1" Carriage Bolt PN 87</p>  <p><b>C</b></p>
<p>1/4" x 3/4" Hex Head Bolt PN 70 PN 70B (Black)</p>  <p><b>J</b></p>	<p>Nylon Bushing (Spacer) PN 116</p>  <p><b>—</b></p>	<p>1/4" x 1 1/4" Hex Head Bolt PN 94</p>  <p><b>—</b></p>	<p>1/4" x 3/4" Carriage Bolt PN 223 Stainless Steel Boards Only</p>  <p><b>—</b></p>