



41185 - Vehicle Wiring Installation Instructions
Chevrolet Impala SS 1994 – 1996
Chevrolet Caprice 1994 – 1996
Buick Roadmaster 1991 – 1996

1. Open rear trunk lid to locate the vehicle wiring inside the vehicle's trunk on the driver's side. Next carefully pull back the trunk liner to expose the vehicles taillight wiring connectors.
2. On the Driver's side, disconnect the vehicle wiring harness from the taillight socket. Plug the Hopkins® T-Connector end with the yellow wire in-between the mating plugs on the driver's side taillight socket and vehicle wiring harness.
3. Route the wire with the 4-flat connector to near the trunk lid latching mechanism.
4. Locate a suitable grounding point on the vehicles frame for the ring terminal on the white wire which is attached to the 4-way flat connector. Clean dirt, paint and rust proofing from area. Drill a 3/32" hole and secure white wire with ring terminal using self tapping screw (provided). Verify what is behind any surface prior to drilling to avoid damage to the vehicle. Do not drill into any vehicle exterior exposed surfaces.
5. Reinstall the trunk liner and any other items removed during the installation. Be careful to avoid any areas that could cut or pinch the wires.
6. Route the 4-way flat harness to either side of the receiver hitch and secure it with ny-ties (provided). The 4-way flat cable is to be rolled up and secured in the trunk when not towing.
7. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
8. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
9. Plug completed wire harness into the trailer 4-way flat connector.
10. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com