



EZ BRACKET™

300031

HONDA PILOT 02-03

Thank you for purchasing one of the many quality items manufactured by Lund Industries, Inc. We take the utmost pride in our products and want you to enjoy years of satisfaction from your investment.

This product has been designed and engineered to correctly fit and complement only the vehicle(s) listed in the heading.


For easiest installation and the best final appearance, read the complete instruction BEFORE you begin.

Please follow all instructions for the proper installation of this part to the vehicle. Lund Industries, Inc.


INSTALLATION KIT INCLUDES



Front Bracket




Front Middle Bracket



Rear Bracket



Rear Middle Bracket



Center Support Bracket



Outer Support Bracket



Self Tapping Screws



1/4" Washers



1/4" Nuts



1/4" bolts



8mm Bolts




5/16" Washers


TOOLS NEEDED FOR INSTALLATION



Socket Set




Standard Wrench Set



Drill



Hammer



Floor Jack




1/8" Drill Bit




Silicone



Center Punch




NOTE: Place truck on level surface.




NOTE: Preassemble boards according to running board instruction sheet.


P.N. 300031 = 4 Brackets / side




NOTE: Raise board into place with floor jack. Center board on rocker panel.



NOTE: Attach support brackets to main bracket using 1/4" bolt, washers, and Nut. Attach support bracket to pinch weld and main bracket to frame using 8mm bolt.




NOTE: Attach support brackets to main bracket using 1/4" bolt, washers, and Nut. Attach support bracket to pinch weld and main bracket to frame using 8mm bolt.



NOTE: Attach support brackets to main bracket using 1/4" bolt, washers, and Nut. Attach support bracket to pinch weld and main bracket to frame using 8mm bolt.

7


MIDDLE - REAR LOCATION



NOTE: Attach support brackets to main bracket using 1/4" bolt, washers, and Nut. Attach support bracket to pinch weld using 8mm bolt. Using rear bracket as a guide, mark hole locations in rocker panel.


8

REAR LOCATION



NOTE: Lower brackets and drill upper holes 1/8" diameter.


9



NOTE: Place a small bead of silicon in each hole.

10

REAR LOCATION



NOTE: Attach support bracket to pinch weld using 8mm bolt. Attach rear bracket to rocker panel using self tapping screws.