X5VI-5520-NAV INSTALLATION INSTRUCTIONS

In the Ford/Lincoln/Mercury vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-5520-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-5520-NAV.

The XSVI-5520-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-5520-NAV does not retain OEM amplifiers.

Wiring the XSVI-5520-NAV: Wiring up the XSVI-5520-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

Navigation wire colors:
Blue/Pink – VSS (Vehicle Speed Sense)
Green/Violet – Reverse
Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-5520-NAV REV. 11/06/07
1-800-221-0932 www.metraonline.com MFTRA FLECTRONICS CORPORATION © COPYRIGHT 2007

X5VI-5520-NAV INSTALLATION INSTRUCTIONS

In the Ford/Lincoln/Mercury vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-5520-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-5520-NAV.

The XSVI-5520-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-5520-NAV does not retain OEM amplifiers.

Wiring the XSVI-5520-NAV: Wiring up the XSVI-5520-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

Navigation wire colors:
Blue/Pink - VSS (Vehicle Speed Sense)
Green/Violet - Reverse
Lt. Green - Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-5520-NAV REV. 11/06/07
1-800-221-0932 www.metraonline.com METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

X5VI-5520-NAV INSTALLATION INSTRUCTIONS

In the Ford/Lincoln/Mercury vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-5520-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-5520-NAV.

The XSVI-5520-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-5520-NAV does not retain OEM amplifiers.

Wirring the XSVI-5520-NAV: Wirring up the XSVI-5520-NAV is like wirring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wirring of your aftermarket radio.

Navigation wire colors:
Blue/Pink – VSS (Vehicle Speed Sense)
Green/Violet – Reverse
Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-5520-NAV REV. 11/06/07
1-800-221-0932 www.metraonline.com Metra Electronics Corporation © Copyright 2007

X5VI-5520-NAV INSTALLATION INSTRUCTIONS

In the Ford/Lincoln/Mercury vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-5520-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-5520-NAV.

The XSVI-5520-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-5520-NAV does not retain OEM amplifiers.

Wiring the XSVI-5520-NAV: Wiring up the XSVI-5520-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

Navigation wire colors:
Blue/Pink – VSS (Vehicle Speed Sense)
Green/Violet – Reverse
Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

REV. 11/06/07

1-800-221-0932 www.metraonline.com Metra electronics corporation © copyright 2007

INSTXSVI-5520-NAV

key off.

X5VI-5520-NAV INSTALLATION INSTRUCTIONS

In the Ford/Lincoln/Mercury vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-5520-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-5520-NAV.

The XSVI-5520-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-5520-NAV does not retain OEM amplifiers.

Wiring the XSVI-5520-NAV: Wiring up the XSVI-5520-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

Navigation wire colors:
Blue/Pink – VSS (Vehicle Speed Sense)
Green/Violet – Reverse
Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn key off.

(See Applications on back of page)

INSTXSVI-5520-NAV REV. 11/06/07
1-800-221-0932 www.metraonline.com Metra Electronics Corporation © Copyright 2007

XSVI-5520-NAV INSTALLATION INSTRUCTIONS

In the Ford/Lincoln/Mercury vehicles listed on back there are no 12 volt accessory wires in the factory radio harness making the installer run an accessory wire to the fuse box or underneath the steering column when installing an aftermarket radio. The XSVI-5520-NAV is designed to provide a 12 volt 10 amp switched accessory output along with the rest of the wires needed to install an aftermarket radio. The R.A.P. (Retained Accessory Power) function is retained by the XSVI-5520-NAV.

The XSVI-5520-NAV also provides essential wires required for aftermarket radios that have navigation. Provided is VSS (Vehicle Speed Sense), Reverse, and Parking Brake. This cuts down the installation time since the installer does not have to look for these wires in the vehicle.

Note: the XSVI-5520-NAV does not retain OEM amplifiers.

Wiring the XSVI-5520-NAV: Wiring up the XSVI-5520-NAV is like wiring up any other wire harness that would attach to the aftermarket radios harness. The Metra/EIA wire code can be found on the back of this package that will aid you in the wiring of your aftermarket radio.

Navigation wire colors:
Blue/Pink – VSS (Vehicle Speed Sense)
Green/Violet – Reverse
Lt. Green – Parking Brake

INITIALIZE THE XSVI INTERFACE BEFORE TURNING ON RADIO: With all connections made and harnesses connected to the vehicle, turn ignition key to the ON position for thirty seconds, then turn

(See Applications on back of page)

INSTXSVI-5520-NAV REV. 11/06/07
1-800-221-0932 www.metraonline.com METRA ELECTRONICS CORPORATION © COPYRIGHT 2007

APPLICATIONS

 FORD

 Edge
 2007

 Escape
 2008

 Expedition
 2007

LINCOLN

 MKX
 2007

 MKZ
 2007

 Navigator
 2007

 Zephyr
 2006

MAZDA

Tribute 2008

MERCURY

Mariner 2008

APPLICATIONS I

FORDEdge2007Escape2008Expedition2007

LINCOLN

 MKX
 2007

 MKZ
 2007

 Navigator
 2007

 Zephyr
 2006

MAZDA

Tribute 2008

MERCURY

Mariner 2008

APPLICATIONS

FORDEdge2007Escape2008Expedition2007

LINCOLN

 MKX
 2007

 MKZ
 2007

 Navigator
 2007

 Zephyr
 2006

MAZDA

Tribute 2008

MERCURY

Mariner 2008

APPLICATIONS I

FORD

Edge 2007 Escape 2008 Expedition 2007

LINCOLN

MKX 2007 MKZ 2007 Navigator 2007 Zephyr 2006

MAZDA

Tribute 2008

MERCURY

Mariner 2008

APPLICATIONS I

FORDEdge2007Escape2008Expedition2007

LINCOLN

 MKX
 2007

 MKZ
 2007

 Navigator
 2007

 Zephyr
 2006

MAZDA

Tribute 2008

MERCURY

Mariner 2008

APPLICATIONS I

FORDEdge2007Escape2008Expedition2007

LINCOLN

MKX 2007 MKZ 2007 Navigator 2007 Zephyr 2006

MAZDA

Tribute 2008

MERCURY

Mariner 2008