

Warn Auxiliary Relays can be used in conjunction with Warn Auxiliary Switch P/N 220020 to control up to 30 amps of current. (The relay itself draws only 1/3 amp)
THIS UNIT MAY REPLACE EITHER 3 OR 5 PRONG RELAYS.

Figure A. for replacement of 3 prong relay.





Figure B. for replacement of 5 prong relay.



CAUTION: Be sure to fuse your circuit at 30 amps or less and use hookup wire that will handle the current demanded by your circuit.

P/N 30761 A0

Warn Auxiliary Relays can be used in conjunction with Warn Auxiliary Switch P/N 220020 to control up to 30 amps of current. (The relay itself draws only 1/3 amp)
THIS UNIT MAY REPLACE EITHER 3 OR 5 PRONG RELAYS.

Figure A. for replacement of 3 prong relay.





Figure B. for replacement of 5 prong relay.



CAUTION: Be sure to fuse your circuit at 30 amps or less and use hookup wire that will handle the current demanded by your circuit.

P/N 30761 A0

Warn Auxiliary Relays can be used in conjunction with Warn Auxiliary Switch P/N 220020 to control up to 30 amps of current. (The relay itself draws only 1/3 amp)
THIS UNIT MAY REPLACE EITHER 3 OR 5 PRONG RELAYS.

Figure A. for replacement of 3 prong relay.





Figure B. for replacement of 5 prong relay.



CAUTION: Be sure to fuse your circuit at 30 amps or less and use hookup wire that will handle the current demanded by your circuit.

P/N 30761 A0