



STEP 1 – PRIOR TO INSTALLATION

- A) Bushwacker only** approves installing the flares according to these written instructions with the hardware provided. **WARNING:** Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. **DO NOT USE:** Loctite, SuperGlue, or similar products on the hardware or the flares.
- B) Fit:** Verify the fit of the flares to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting:** (Optional) if paint is desired it must be done prior to installing flares on vehicle. Clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer’s recommendations is required. Paint flares using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.
- D) Performance:** Using larger Tires may increase the area required to turn the vehicle. Some Tire/Rim combinations may require lowering bump stops and or installing steering stops to prevent tire from contacting flare.
- E) Exhaust System:** Modifications may be necessary to maintain a minimum 4” clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)
- F) Metal Protection:** All exposed fasteners and bare metal should be treated with rust resistant paint **BEFORE** installing flares. Spray inner fender wells with undercoating **AFTER** flare attachments have been completed.
- G) Decals:** Flares may interfere with existing decals on vehicle. If you wish, remove decals prior to installation of flares.

RAM “OE” Style® Fender Flares Set of 4

Set Part #50917-02
Rev-5 08/18/2014

For complete fitment info visit : www.bushwacker.com

TOOLS FOR EASY INSTALLATION:

- Utility Knife
- Drill
- 1/8” Drill Bit
- #2 Phillips Driver
- Socket Wrench
- 8mm Socket
- 3/8” Wrench
- Awl or Similar Pointed Tool
- Grease Pencil

LIMITED LIFETIME WARRANTY AGAINST ANY MANUFACTURING DEFECTS

- To claim a warranty, you must provide Proof of Purchase.

Included in Hardware Kit:

- | | | | | | | |
|---|--|---|---|---|---|---|
| 1.

CL1-0001,
.185-.225
SS “U” Clip,
4 pcs | 2.

CL1-0022,
#10 “U” Clip,
4 pcs | 3.

ET1-0002,
Edge Trim Tool,
1 pc | 4.

GP1-0005,
Large Wiper Style
Edge Trim,
325 inches | 5.

MT1-0014,
1” x1.5” x.01”
Black Tab,
10 pcs | 6.

NU1-0004,
10-24 Nylon Nut,
2 pcs | 7.

SW1-0003,
10-24 x 3/4”
Phillips PH Screw,
2 pcs |
| 8.

SW1-0050,
10 x 5/16 Phillips
Truss Screw,
2 pcs | 9.

SW1-0056,
#8 x 3/4”
PH Screw,
12 pcs | | | | | |

STEP 2 - EDGE TRIM INSTALLATION


- A)** Peel two to three inches of red vinyl backing away from Wiper Style Edge Trim tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the vehicle).
- B)** Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.




Front Flare Installation Procedures (Driver's Side):



Using dimple in front piece as a guide, drill a 1/8" hole and install supplied screw (SW1-0050) through the drilled hole.



Bolt front main flare and front pieces together with supplied screw (SW1-0003) and supplied nut (NU1-0004). Use a 3/8" wrench to hold nut in place.




Secure pieces with two SS U-Clips (CL1-0001) to prevent rotation out of alignment after installation.



Install two 1"x1.5" Black Tabs (MT1-0014) over seam between main vehicle body and headlight mounting.




Take one 1"x1.5" Black Tab and bend it at an approximately 90 degree angle.



Measure 3.25" from wheel well along headlight mounting and mark with a grease pencil. Remove white backing from 1"x1.5" Black Tab. Center tab at mark, hook around lip, and install.



All three 1"x1.5" Black Tabs.



Remove four factory installed screws with 8 mm socket wrench.



2011 Models Only: Remove inner piece at bottom rear of wheel well.



Install supplied clip (CL1-0022) at this location. See Steps 11, 12, 13, & 14.



11

At location indicated in step 10, there is a lip with two factory holes. One hole is a circle and one is an oval. The 1"x1.5" Black Tab (MT1-0014) and clip (CL1-0022) will be installed over the oval. The oval is the hole more toward the front of the vehicle.




12

Install 1"x1.5" Black Tab over existing factory hole.




13

Install clip (CL1-0022) over 1"x1.5" Black Tab.



14


Using an awl or similar pointed tool, poke a hole through 1"x1.5" Black Tab using the clip hole as a guide.



15


10 x 5/16
Phillips Truss
Screw

When fitting flare on vehicle, first position front piece. The Truss Tap Screw (SW1-0050) hooks behind where folded 1"x1.5" Black Tab was installed in step 6.




16

Kit supplied screw locations. See step 17.



Hold flare to vehicle and start the kit supplied screws (SW1-0056) with a Phillips screwdriver. *Do not tighten.*



Press firmly on flare and tighten all screws.



Completed front flare installation.


Rear Flare Installation Procedures (Driver's Side):



Remove these five factory installed screws using an 8mm socket wrench. Keep screws for installation of the rear flare. X's indicate a factory screw that will not be removed.



Install clip (CL1-0022) in this location. See Steps 22, 23, & 24.




22

Install 1"x1.5" Black Tab (MT1-0014) over existing factory hole.



23

Install clip (SW1-0022) over 1"x1.5" Black Tab.



24

Using an awl or similar pointed tool, poke a hole through 1"x1.5" Black Tab using the #10 U-Clip hole as a guide.




25

Kit supplied screw and factory installed screw locations. See Steps 26 & 27.



26

Hold flare in place while you start factory screws using an 8mm socket wrench. *Do not tighten.*



27

Start supplied screw (SW1-0056) using a Phillips screwdriver. *Do not tighten.* Pictured here is the top center screw location of the rear wheel well.




Press firmly on flare and tighten all screws.



Completed rear flare installation.

Edge Trim Tool Procedures:



Using supplied Edge Trim Tool, seat Wiper Style Edge Trim against vehicle by hooking curved end under edge trim at one end of flare. Next, slide around outer edge of flare to the other end.



Using flat end of supplied Edge Trim Tool, seat edge trim against flare by inserting straight end between edge trim and flare at one end. Next, slide around entire edge to the other end.