



advanced FLOW engineering

Instruction Manual P/N: 46-70180 / 46-70182

Make: **Ford** Model: **Super Duty F-250/F-350** Year: **2011-2021** Transmission: **6R140**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.

Retain factory parts for future use.

Label	Qty.	Description	Part Number
A1	1	Trans. Pan - Raw, Machined Fins (46-70180)	05-60342A
A2	1	Trans. Pan - Black, Machined Fins (46-70182)	05-60342
B	19	Screw M6 x 1.0 x 30mm bolts	03-50382
C	19	M6 washers	03-50177
D	1	Plug, Square Socket Head, 3/4" - 14 NPTF Magnet	03-50222
E	1	Plug, Hex Head Socket, 1.8" - 27 NPT (Zn Plt)	03-50029
F	1	Screw M6 x 8 x 1.0mm	03-50407
G	1	Fender washer	03-50412

Installation will require the following tools:

8mm Socket, Socket Driver(Ratchet), 1/2" Extension, 1/2" Ratchet, 5/32" allen wrench, 5mm Allen wrench
4mm Allen wrench, Thread locker, Teflon tape, Transfer pump for oil, Lint free rags.

Warranty Information available at: <https://afepower.com/contact#warranty>

A1



A2



B



C



D



G



E



F



**Figure A****Refer to Figure A for steps 1-3**

Step 1: Park vehicle on flat dry surface and engage the parking brake.

Step 2: Using a 13mm wrench, remove the drain plug and allow the oil to drain into a drain pan.

Step 3: Using an 8mm socket, remove the 19 bolts holding the transmission pan.



Figure B

Refer to Figure B for steps 4-5

Step 4: Remove the stock filter from the transmission. Make sure that the rubber seal on the transmission filter comes out with the filter.

Step 5: Wipe any residual transmission fluid from the transmission with a lint free rag.

aFe recommends replacing filter at this time.



Figure C

Refer to Figure C for steps 6-7

Step 6: Remove the magnet from the factory Ford pan.

Step 7: Install the magnet on the aFe transmission pan and retain using the supplied M6-1.0 bolt and fender washer. Make sure to use a drop of thread locker on the bolt and carefully tighten.

**Figure D****Refer to Figure D for steps 8-10**

Step 8: Install teflon tape on the $\frac{3}{4}$ " NPT plug, and on the $\frac{1}{4}$ " NPT plug.

Step 9: If not installing a temperature sensor, use a $\frac{5}{32}$ " allen wrench and install the $\frac{1}{8}$ " NPT into the transmission pan.

Step 10: Using a $\frac{1}{2}$ " extension and a $\frac{1}{2}$ " ratchet, install the $\frac{3}{4}$ " NPT plug into the

transmission.

**Figure E****Refer to Figure E for steps 11-13**

Step 11: Install the filter into the transmission.

Step 12: Using the factory gasket, install the new aFe transmission pan using a 5mm allen wrench and (19) M6x30mm.

Step 13: Fill the transmission pan with the oil recommended by Ford, (Mercon\LV). Follow the directions in your owner's manual on how to check the level on the transmission dipstick.

***You Installation is now complete.**


Note: Transmission fluid expands. Always check oil level when the truck is at operating temperature.

Page left blank intentionally



Page left blank intentionally

Page left blank intentionally



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879
TEL: 951.493.7100