



INSTALLATION INSTRUCTIONS

MAKE: Chevrolet

MODEL: Corvette (C7) / Z06 (C7)

YEAR: 2014-2019

ENGINE: V8-6.2L & Supercharged w/ Auto

TRIM: All trim levels.

NOTE: Does NOT fit Manual Transmissions.

304 SS Twisted Steel

3" X-Pipe

48-34129-YC (w/ Cats.)

48-34129-YN (w/o Cats.)



Parts Included:

- Clamp, 2-3/4" (x2)
- Screw, Hex Hd Cap: M10 (x4)
- Nut, Flg M10 (x4)

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

1. Remove your stock X-pipe by removing the (X4) nuts on the front flanges, the (X2) bolts on the OE hanger bracket, and then loosening the band clamps at the rear.
2. Remove the OE Gaskets and hanger bracket from the OE X-pipe and install onto the new aFe Power X-pipe.
3. Install New X-pipe using the OE hanger bracket, Bolts and the (X4) provided nuts, bolts and (X2) 2-3/4" band clamps.
4. Adjust system and tighten all nuts, bolts and clamps.
5. Congratulations your system is now fully installed. It is recommended to re-check and tighten all nuts, bolts and clamps 50-100 miles after first install.



RACE ONLY DISCLAIMER

This is a Race Only product that is to be used solely for competition, it cannot be used on vehicles that are operated on public streets, roads or highways. Its use is limited to closed-course and open-course racing that is formally sanctioned by a recognized racing organization. Any other use, including recreational off-road use, could be in violation of local, state and federal laws. A competition acknowledgement / liability release form must be filled out and submitted.

NOTES: aFe recommends that the tailpipe be at least 1/2"-1" away from any body panels to avoid heat related body damage. **Tighten and secure.**

Caution: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on our product**