



advanced FLOW engineering

SCORCHER HD Module

Instruction Manual P/N: 77-42006


Make: **Dodge** Model: **2500/3500 HD** Year: **2003-2004** Engine: **L6-5.9L (td) Cummins**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Module	R77-42006
B	1	LED Switch	05-70005
C	2	Velcro (2 Inches)	05-01244
D	4	Cable Ties	05-60167

Warranty Information available at: <https://afepower.com/contact#warranty>



**Figure A****Refer to Figure A for Step 1.**

Step 1: Locate the MAP ① and Fuel Pressure sensor ②. They are both close to each other and are located on the driver side next to the intake manifold.



Figure B

Refer to Figure B for Steps 2-3.

Step 2: Disconnect the MAP sensor.

Step 3: Locate the MAP sensor jumper harness on the aFe module. This is the longer harness with a Blue and Black connector. Plug the male connector of the module to the stock map sensor, then the female connector of the module male connector of the engine harness.

Note: Make sure connections are fully engaged. Usually, connectors make a snapping sound when fully engaged.



Refer to Figures C for Steps 4-5.

Step 4: Locate and disconnect the fuel pressure sensor.

Step 5: Locate the fuel pressure sensor jumper harness on the aFe module. This is the shorter harness with an Orange and Black connector. Plug the male connector of the module to the stock fuel pressure sensor, then take the female connector of the module and connect to the male connector of the engine harness.



Figure D

Refer to Figure D for Steps 6-7.

Step 6: Carefully route the switch cable behind steering wheel cover.

Step 7: Mount the Switch on an open, flat surface.



Refer to Figure E for Step 8.

Step 8: Route the switch cable through firewall and into the engine bay. Follow the main harness through the grommet into the firewall. Plug the end of the cable to the module.

**Figure F****Refer to Figure F for Step 9.**

Step 9: Mount the module in a safe location, using the supplied Velcro strip. Then, secure the wires and module away from any extreme heat and moving parts, with the provided ties. Make sure all connections are secured and fully engaged.

**Figure L****Refer to Figure L for Step 24.**

Step 24: When turning on the vehicle, the switch will go through the light. It will stop at its last setting.

The LED on the switch represents the different level of power.

- Green LED: Stock
- Yellow LED: Sport
- Orange LED: Sport+
- Red LED: Race

Use the grey button to select the desired setting. Power adjustments can be done at any moment.

NOTE: Place enclosed CARB EO sticker on or near the device on a smooth, clean surface.

EO identification label is required to pass the smog test inspection.

Page left blank intentionally



advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879

TEL: 951.493.7100

E-Mail: Tech@aFepower.com

P/N: 06-80818