



Installation Instructions

For Part Numbers:

400-793 850-385 Airaid Oiled Media Filter

401-793 851-385 SynthaMax Dry Media Filter - Red

2015-20 FORD F150


V8-5.0L

NOT LEGAL FOR SALE OR USE ON ANY POLLUTION CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.

See Airaid.com for CARB status on each part for a specific vehicle

TOOLS NEEDED:

flat blade screw driver



Component Identification

| Description | Qty. | Part # |
|----------------------------|------|-------------|
| A HOSE CLAMP #56 | 2 | 08620 |
| B HOSE; 3-5/8"ID X 1.75"L | 1 | 08615 |
| C INTAKE TUBE (MQ) | 1 | KIT793A |
| D VENT; 1/4 NPT QUICK | 1 | 082628 |
| E VENT; STRT, 1/4NPT QUICK | 1 | 08938 |
| F HOSE CLAMP #60 STAINLESS | 2 | 08628 |
| G HOSE; HUMP REINFORCED | 1 | 08683 |
| H FILTER | 1 | 850/851-385 |

Full color instructions can be viewed on our web site at Airaid.com. If you need any assistance please call 1-800-498-6951 to speak with a representative in our Customer Service Center before returning the product.

TO START:

1. Turn off the ignition and disconnect the negative battery cable.

NOTE: Disconnecting the negative battery cable erases pre-programmed electronic memories. Write down all memory settings before disconnecting the negative battery cable. Some radios will require an anti-theft code to be entered after the battery is reconnected. The anti-theft code is typically supplied with your owner's manual. In the event your vehicles anti-theft code cannot be recovered, contact an authorized dealership to obtain your vehicles anti-theft code.



2. Disconnect the EVAP and crank case vent quick disconnect fittings.



3. Loosen the hose clamps that secure the factory intake tube to the air filter housing and throttle body and then remove the intake tube from the vehicle.

NOTE: AIRAID recommends that customers do not discard factory air intake.



4. Release the two clips that secure the upper air filter housing and then remove the upper housing and factory air filter.



5. Install the provided AIRAID® air filter and reinstall the factory upper air filter housing.



6. Install the provided vent fittings into the AIRAID® intake tube as shown. Install the provided hump coupler (08683) onto the intake tube and secure with the provided hose clamp.

NOTE: NPT fittings are easy to cross thread. Install the vent fitting "hand" tight, then turn it two complete turns with a wrench.

Continued...



7. Install the provided coupler hose (08615) onto the throttle body and secure with the provided hose clamp.



8. Install the AIRAID® intake tube into the coupler at the air filter housing and then into the coupler at the throttle body, adjust the tube for best fit and then secure with the provided hose clamps.



9. Connect the EVAP and crank case vent lines to the quick connect fittings installed into the AIRAID® intake tube.



10. Double check your work!

Make sure there is no foreign material in the intake path. Make sure all clamps, hoses, bolts, and screws are tight. Double check the hood clearance!

Reconnect the negative battery cable!

Thank you for purchasing the Airaid Intake System. Contact Airaid @ (800) 498-6951 8:00 AM - 5:00 PM MST weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid Intake System was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, contact Airaid. The air filter element is protected from direct exposure to water and debris; care should be taken not to drive through deep water.

WATER INGESTION IS THE DRIVERS RESPONSIBILITY! The air filter is reusable and should be cleaned periodically.

FILTER IDENTIFICATION

850-385 Airaid Oiled Media

851-385 Airaid SynthaMax Dry Media - Red

For your Oiled media filter we offer the
Airaid Tune Up Kit!



P/N 790-551 Aerosol Spray
P/N 790-550 Squeeze Spray



NOT LEGAL FOR SALE OR USE ON ANY POLLUTION CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.

See Airaid.com for CARB status on each part for a specific vehicle

SynthaMax

Synthamax Air Filters **do not** require oil. Service air filter as needed by cleaning with common non-petroleum all-purpose household cleaner and water. Simple Green®, Formula 409® or equivalent works great. Apply cleaner to outside of air filter and allow to soak. Then flush filter clean from the inside out with a garden hose and repeat steps if necessary. Do not apply high pressure water or air to clean filter. Allow filter to air dry and reinstall.