

# 56086 HONDA PILOT

## WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

2/20/2014




### English

1. Open the rear hatch and fold the rear seats down. On the driver's side open the rear storage compartment (A). Inside the rear storage compartment remove the access panel (A). Behind the panel locate the vehicle's OEM harness connector (B). The connector will mate with the one on the converter. Insert the connector into the vehicle's connector. Make sure the connectors are fully inserted with locking tabs in place.

2. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

3. Adhere the black converter box to the frame of the car using the double-sided tape provided (C). Secure any loose parts of the T-Connector with the cable ties provided. Insert 10 AMP fuse provided into red inline fuse holder.

4. On the driver's side remove the cover labeled AUX FUSE (D). Remove the black cover that is covering the fuse panel (E). Insert 7.5 amp fuse into Position 1. Insert 20 amp fuse into Position 4 and insert relay into Position 6 as shown (H).



5. Behind the rear bumper on the driver's side locate the vehicle's trailer wiring harness connector. The connector will mate with the one on the wiring harness. Remove the connector from the crossmember using a pry tool. Remove dark blue fastener from housing by sliding out. Remove the protective cover being sure not to damage the locking tabs (G). Insert the connector into the vehicle's connector. Make sure the connectors are fully inserted with locking tabs in place.

6. Route and secure the 4-flat to the center of the vehicle in a convenient out of the way location. Secure any loose wires with the cable ties provided.



7. On the driver's side under the hood, locate the fuse box and remove black plastic cover (I). Insert 20 amp SLO-BLO fuse into position as shown (J).

8. Reinstall all items removed during install.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.



56086