


INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Chevrolet	Traverse

CUSTOM WIRING CONNECTOR



WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S5 - Behind driver side rear bumper



NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

Ratchet	Flat blade screwdriver
15mm socket	Panel trim removal tool
Socket extension	Cutting tool

⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 7.5 amps per side
Tail / Running Circuits - 7.5 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Above the muffler on the driver side, locate the vehicle taillight wiring. Lower the muffler to access the vehicle taillight wiring connector.

Note: It may be necessary to use the trim panel removal tool to pry the connector away from the vehicle frame. If there is not enough room to use the trim panel removal tool, remove the bolts securing the muffler bracket in place (A,B).

Step 2

The vehicle connector will be similar to the connector on the custom wiring connector. Separate the connectors from the taillight housing taking care not to damage the locking tabs (C).

Step 3

Insert the custom wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.

Step 4

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties

  **WARNING:** Route the wiring away from potentially hot surfaces such as the muffler, heat pipes, and heat shields.

Step 5

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

