



# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Honda	Accord Sedan

## CUSTOM WIRING HARNESS



## WIRING LOCATION GUIDE

### PASSENGER CARS (P)

Representative vehicle shown below

P1 - Behind driver side taillight housing, outside of trunk

P2 - Behind passenger side taillight housing, outside of trunk



### NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

Ratchet

Ratchet extension

10mm socket

Phillips screwdriver

Panel trim removal tool

Wire stripper

Wire crimper

Cutting tool

Fish wire

## ⚠ WARNING

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side

Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Open the vehicle trunk (A). Remove all trunk floor coverings.

## Step 2

Starting on the driver side, locate and remove the taillight trim cover (B). Locate and remove the two fasteners that are securing the taillight in place (C).

## Step 3

Remove the taillight by gently pulling outward. Take care not to damage the alignment tabs located on the back of the taillight.

## Step 4

Locate the vehicle taillight wiring harness connectors on the back of the taillight. The connectors will be similar to those on the custom wiring harness (D). Separate the connectors from the taillight housing taking care not to damage the locking tabs. Set taillight off to the side for later use.

## Step 5

From underneath the vehicle, route the custom wiring harness with the yellow wire along the rear bumper and up behind the fender to the opening underneath the removed taillight (E).

## Step 6

Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place. Reinstall the taillight.

## Step 7

Locate a suitable grounding point near the connector such as an existing screw with a nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

  **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 8

Route the custom wiring harness end with the green wire to the passenger side along the rear bumper. Repeat steps 2 - 6 on the passenger side using the harness end with the green wire.

## Step 9

Locate a flat clean surface that is out of the path of spray and debris from the rear wheels and road. Adhere the black converter box using the provided double-sided tape (F).

## Step 10

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

## Step 11

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out-of-the way location inside the trunk. Secure any loose wires with the provided cable ties. Use the provided cable ties to secure any loose wires.

## Step 13

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

