INSTALLATION INSTRUCTIONS

🛦 WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Mak	e
Jeer	

Model Wrangler JL Unlimited

CUSTOM WIRING HARNESS





WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

- S1 Behind driver side taillight housing
- S2 Behind passenger side taillight housing



NOTICE 🗢 🖽

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

Ratchet Ratchet extension T-30 Torx bit Flat blade screwdriver Wire stripper Wire crimper Cutting tool Fish wire

🛦 WARNING 🛦 🔺

The battery connection must be fuse-protected, 10-amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side Tail / Running Circuits - 6.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Open the vehicle tailgate.

Step 2

Starting on the driver side, locate and remove the small trim access cover from the side interior panel (A).

Step 3

Under the small access cover, locate and remove the fastener securing the taillight in place (B,C).

Step 4

Remove the taillight by gently pulling outward (D). Take care not to damage the alignment tabs.

Step 5

Locate the vehicle taillight wiring harness connectors on the back of the taillight. The connectors will be similar to those on the custom wiring harness (E). Separate the connectors from the taillight housing taking care not to damage the locking tabs. Set the taillight aside.

Step 6

Route the custom wiring harness with the yellow wire from inside the removed taillight cavity out the hold to the removed taillight (F,G).

Step 7

Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

Step 8

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

WARNING: Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

Step 9

Route the custom wiring harness end with the green wire to the passenger side behind the removed scuff panels. Repeat steps 2-7 on the passenger side using the harness end with the green wire.

Step 10

Locate a flat clean surface behind the driver-side removed taillight, inside the fender well (G). The area should be out of the path of spray and debris from the rear wheels and road. Adhere the black converter box using the provided double-sided tape. Failure to mount the box in a protected area can cause loss of warranty, product failure, overheating and potential fire.

Step 11

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

Step 12

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location (H). Secure any loose wires with the provided cable ties.

Step 13

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.















