



Truck and Jeep Accessories

ESTABLISHED IN 1977



LIKE US




SHARE US



WATCH US



FOLLOW US



Truck and Jeep Accessories

KC09140BK

2017 and UP RAM 1500 2WD/4WD 1" REAR LIFT KIT

KC09143BK

2019 and UP RAM 1500 2WD FRONT 2" LEVELING KIT

KC09144BK

2019 and UP RAM 1500 2WD FRONT AND REAR 2" LIFT KIT



FRONT SPACERS



REAR SPACERS

www.Daystarweb.com

Tech Support Contact Info

Tech@DaystarWeb.com

Phone: 623.907.0081

Fax: 623.907.0088

841 South 71st Avenue

Phoenix, AZ 85043

Instruction Sheet: INS09143

2019 Daystar Products International Inc.

Revision: 00

Revision Date: 2/1/2019

Revised by: MF

Introduction



is your number one source for Made In The USA quality, Comfort Ride™ leveling kits. Now backed with our exclusive *Go Everywhere* © Lifetime Limited Warranty (see terms at Daystarweb.com). To assure your safety and

proper installation of this product, take a moment to read all instructions and Product Safety Information before trying to install your Daystar® product. Current OEM suspension design is complex: meaning safe and proper installation requires understanding OEM service techniques for disassembly and assembly of the components indicated together with the instructions and warnings set out below and in the OEM service manual and your owner's manual. *Daystar® strongly recommends seeking advice from or having this product installed by a professional mechanic who can inspect your suspension, confirm compatibility with your tire and wheel choice and, if needed, reset alignment to optimize your steering and the features of your Daystar® Comfort Ride kit.* We are here to help if you have remain-

Product Safety Information

Throughout these instructions important safety information is generally preceded by one of three signal words indicating the relative risk of injury. The signal words mean:

! WARNING A hazardous situation which, if not avoided, could result in death or serious injury. You can be Killed or Seriously Hurt if you don't follow instructions.

! CAUTION A hazardous situation which, if not avoided, could result in minor or moderate injury. You can be moderately HURT and also may suffer property damage if you don't follow instructions.

NOTICE Careful attention is required to this instruction or operation but does generally not relate to personal injury. Damage to your product or other

!WARNING

Familiarize yourself with all vehicle manufactures' and Daystar warnings, instructions and limited warranties before driving your modified suspension vehicle. Also be aware many states / countries have laws governing on-road vehicle heights and modifications. You are responsible for assuring the safety and legality of your vehicle. A summary of current state vehicle laws is available at www.sema.org.

DAYSTAR
Truck and Jeep Accessories

MADE IN THE USA

CARRY MORE WITH CAM CANS

SAFE & SECURE FLUID & GEAR STORAGE

NEW

Cam Can Trail Box
 KU71140R Cam Can Trail Box (Trail Box Only) \$69.99
 KJ710350R Cam Can Trail Box (Jeep Complete Kit) \$129.99
 KT710010R Cam Can Trail Box (Toyota Complete Kit) \$129.99

Cam Can Universal Mounting Kit
 KU71118 Mount your Cam Can on the garage wall, trailer or any other flat surface. \$49.99

Double Cam Can Mount
 KU71116 Double-mount kit available. Includes a longer center shaft and allows you to stack two Cam Cans together on the mounting plate. \$19.99

A. Cam Can Drinking Water
 KU71114RB (Cam Can Only) \$59.99
 KJ71035RB (Jeep Complete Kit) \$119.95
 KT71001RB (Toyota Complete Kit) \$119.95

B. Cam Can Fluids (Non-Fuel)
 KU71114GN (Cam Can Only) \$59.99
 KJ71035GN (Jeep Complete Kit) \$119.95
 KT71001GN (Toyota Complete Kit) \$119.95

AS EASY AS...

- 1
- 2
- 3

AIR BAG CRADLE

MADE FROM EXTREMELY TOUGH DAYSTAR PTMEG POLYURETHANE **KU09140BK \$79.99**

Get all the benefits of an air bag cradle whether you are towing a heavy load or not

GO EVERYWHERE
daystarproducts.com 800-595-7659

What is Covered? Real Life Use, Off Road & On: Subject to the terms, exclusions and limitations herein, Daystar® warrants to the initial retail purchaser that your Comfort Ride™ or Budget Boost™ leveling kit shall be free of defects in material and workmanship for so long as it is properly installed on a single vehicle owned by the initial retail Daystar® purchaser.

What is Not Covered? Your Vehicle & Parts Not Daystar’s GoEverywhere:

Your Daystar **Limited Warranty** does not cover: (a.) damage to your vehicle, vehicle systems (ex. electronic stability control) other products, components or property not manufactured by Daystar to our exclusive *GoEverywhere* standards, (b.) customer choice of vehicle configuration/tire and wheel combinations contrary to Daystar® recommendations, warnings or applicable laws, (C.) Acts of God, weather, corrosion, accidents, theft, vandalism, negligent misuse or intentional damage, other exclusions under your OEM Limited Warranty.

Remedy Limited to Repair/Replacement. Get back on your favorite trail fast. The exclusive remedy provided hereunder shall, upon Daystar’s inspection and option, be either repair or replacement of the Comfort Ride™ or Budget Boost™ leveling kit or parts covered under this **Limited Warranty**. Call us and we will get you back wheelin’ (623/907-0081). All labor, removal, shipping and installation costs are customer’s responsibility.

Other Exclusions –Limitation of Damages - Your Rights Under State Law. Stuff Lawyers Say.

At Daystar® we aren’t big fans of lawyers, even ours. Still, he says our **Limited Warranty** has to include this stuff. In consideration of the purchase price paid, neither Daystar® nor any independent Daystar® distributor or repair person are responsible for any time loss, loss of vehicle use, rental costs, transportation, labor or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. No Daystar® employee or independent distributor is authorized to make any statement or representation altering the terms of Daystar’s *GoEverywhere Lifetime Limited Warranty*. **Your exclusive remedy hereunder for covered parts is repair/replacement as described above.** This **Limited Warranty** gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability, fitness for a particular purpose or other implied warranty are limited to a period of four (4) years from date of initial retail purchase. Daystar® reserves the rights to: (a.) require invoice or other proof of purchase; (b.) make future revisions to these products and **Limited Warranty** without prior notice or obligation to upgrade your Daystar® product.

© Daystar Products International, Inc., 9.15.13. All rights reserved.

Tools Needed

Quantity	Description
1	Floor Jack
2	Jack Stands
2	Wheel Chocks
1	Lug Wrench
1	Breaker Bar
1	Ratchet
1	Metric Socket Set
1	Metric Wrench Set
1	Torque Wrench
1	Coil Spring Compressor
1	Ball Joint / Tie Rod Separator

Bill of Materials / Part list FRONT KIT KC09143BK REAR KIT KC09140BK FRONT AND REAR KIT KC09141BK

Quantity	Part Number	Description
	KC09143	FRONT KIT
2	M09143	Front Coil Spring Spacer
	KC09140	REAR KIT
2	3000000	Rear Coil Spring Spacer
	KC09144	FRONT AND REAR KIT
-	-	All Above Components

Installation Instructions

!Warning: Always work with appropriate personal safety gear including safety glasses, gloves and hearing protection if using air powered tools.

Begin by inspecting the components & hardware for damage. Then compare components & hardware to the bill of materials for completeness. If anything is missing/damaged, do not proceed with the installation. Please, call Daystar Products (800-595-7659) and we will send you the missing or damaged components free of charge.

!Caution: Vehicle front end must be raised to install leveling kit. Using a hydraulic chassis lift will greatly ease installation. If another jack is used, assure vehicle is level on a firm surface, in park (1st gear), rear wheels blocked and jack stands in place to support vehicle in case jack or vehicle shifts.

IMPORTANT NOTE: The advertised amount of lift that this kit provides and the thickness of the spacers supplied will not be the same! For example, a 2-1/2” lift may only have 1-1/2” thick spacers. The reason for the difference between the spacer thickness and the amount of lift has to do with suspension geometry. There is a ratio involved, and it is this ratio that determines the thickness of the spacers. Rest assured, installing the spacer supplied will result in the proper amount of lift out at the wheel.

1. Check to see that the spacer kit you purchased matches the year and model of your vehicle. Spacer kits two inches or taller may require a spring compressor to install. Ball joint and tie rod forks may also be useful.
2. A good portion of your front suspension will be disassembled so this would be a good time to replace any worn parts (i.e. tie rod ends, ball joints, idler arm and any bushings) Replace bushings with polyurethane replacement parts.

14. Torque the lug nuts to 85 ft.lbs. using an X pattern.

!Caution: Have an alignment professional check and Adjust the alignment to factory specifications.

15. With the vehicle on the ground inspect suspension components, brake lines and tires to ensure there are not any clearance issues. Jounce the suspension to assure front suspension operates freely, brake lines retain proper slack at full extension and that they remain clear of springs or other obstructions.
16. Install “Warning to Driver” decal on the vehicle’s sun visor or dash. The decal must be placed in a conspicuous location. Anyone that operates the vehicle must be made aware of the changes made.
17. After 25 miles of driving re-torque the lug nuts to 85 ft.lbs..
18. After 500 miles of driving re-torque all of the hardware asso-

2” Lift Kit Installed




Daystar® Lifetime GoEverywhere Limited Warranty

Your Daystar® Comfort Ride or Budget Boost leveling kit is covered by the following **Go Everywhere Lifetime Limited Warranty.**

Rear Suspension Cont.

6. On both sides, remove the sway bar end link nuts at the axle. On the driver side, remove the track bar bolt.



7. Lower the axle and remove the spring and stock spring isolator pad.
8. Install the lift spacer on the top of the spring with the spring properly positioned in the spacer helix. The factory isolator is not re-used.
9. Reinstall the spring/spacer assembly into spring seat with the spacer on top. Be sure the spring and spacer are properly seated on the axle and frame
10. Jack up the axle so you can reinstall the sway bar end link and shocks.
11. Then then double check the installation.
12. Reinstall driver and passenger tires and wheels.
13. Remove jack stands and lower the truck back on the ground. Remove all jacks and jack stands from under vehicle.

3. Jack up vehicle as high as possible using jack stands for support at all times.
4. With vehicle safely off the ground remove front tires. It is advisable to disassemble on side at a time so that you can use the other side as a reference for re-assembly .
5. Remove the brake caliper from the rotor (attached with 2 bolts inside the caliper or with press-in clips depending on the vehicle). Do not remove the brake line from the caliper unless you intend to bleed the brakes at this time. Set the caliper aside or tie it up to the frame rail. Avoid pinching the brake line.
6. Remove the tie rod from the spindle using the proper tools. Do not hit the tie rod itself or the nut on the threaded portion of the tie rod or it may cause damaged and need replacing.
7. Remove the anti-sway bar from the lower control arm. This would be a good time to replace the end link bushings with polyurethane replacement bushing.
8. If your vehicle is equipped with anti-lock brakes you must now disconnect the front rotor sensor from the dust shield or spindle and set it aside.
9. Disconnect your shock absorber completely from the vehicle whether it is mounted inside the coil spring or not.


10. Support the lower control arm with jack just touching the arm. This will prevent it from dropping when the ball joint is disconnected.
11. The use of a coil spring compressor is recommended before the following steps are taken. **CAUTION:** Spring will be under extreme compression use caution when removing.
12. Disconnect the upper ball joint from the top of the spindle using the proper tools. Do not hit the ball joint or the threaded end of the ball joint. Once the ball joint is free the spindle should move easily.
13. Be careful when lowering the lower control arm. The coil spring is under high compression and may shift when released. **CAUTION:** Do not stand near the side of the truck during this step. Lower the jack so that the lower control arm swings down. If the coil spring has not fallen out on it's own you may need to use a pry bar from the front of the vehicle to remove it.
14. **NOTICE:** Which end of the coil spring is "bottom" for installation. Also note the depression in the lower control arm. It is important that the last winding of the coil spring fit into the indentation completely so that the vehicle will sit level.
15. **NOTICE:** Do not switch coil springs from side to side as some vehicles have a specific "right" and "left" coil spring.
16. Check the coil spacer for proper fitment into the coil spring mount in the frame. The flat part of the spacer should face up and touch the top of the spring mount. Some vehicles have guiding tabs to center the coil spring in its top mount. These tabs may have become bent and need to be bent back to allow the spacer to



Truck and Jeep Accessories

REAR SUSPENSION

1. Read instructions completely, verify bill of materials and determine if you have the correct tools before beginning installation.
2. Chock front tires and raise the rear of vehicle placing jack stands under the frame rails so the tires are off the ground .
3. Support the rear axle with a floor jack.
4. Remove the rear wheels.
5. On both sides, remove the lower shock bolt and nut at the axle.



23. Remove jack stands and lower the truck back on the ground. Remove all jacks and jack stands from under vehicle. Torque the lug nuts to 85 ft.lbs. using an X pattern
24. With the vehicle on the ground cycle the steering wheel side to side and inspect suspension components, brake lines and tires to ensure there are not any clearance issues. Jounce the suspension to assure front suspension operates freely, brake lines retain proper slack at full extension and that they remain clear of springs or other obstructions.

Your vehicle may sit too high at first because the suspension needs to settle. **NOTICE:** drive vehicle for at least 25 miles for suspension to settle in to proper ride height.

Caution: Have an alignment professional check and adjust the alignment to factory specifications.

25. Install “**Warning to Driver**” decal on the vehicle’s sun visor or dash. The decal must be placed in a conspicuous location. Anyone that operates the vehicle must be made aware of the changes made.
26. After 25 miles of driving re-torque the lug nuts to 85 ft.lbs.
27. After 500 miles of driving re-torque all of the hardware associated with the leveling spacer installation to factory specifications. Repeat torquing procedure as required.

17. Install the coil spring with the spacer on top of it. If you used a coil spring compressor it should still be on the spring in a compressed state. If not you may need to compress the spring before re-installing. Make sure the spacer is centered in the upper mount and the bottom of the spring is properly nested in the receptor groove on the lower control arm. If you are installing a two-inch or taller spacer you may need a spring compressor. **CAUTION:** Follow all safety rules when installing the coil spring as it will be under extreme compression.
18. Raise the lower control arm with a jack once the coil spring and spacer are properly lined up. Raise until the spindle is high enough to bolt on the upper ball joint. Before bolting on the upper ball joint make sure the brake caliper and brake line are where they need to be since some brake lines run inside the spindle and outside the coil spring.
19. With the upper ball joint tight and a cotter pin re-installed you may now remove the jack from under the lower control arm.
20. Assemble all of the components previously removed (sway bar with new polyurethane bushings, tie rod ends with polyurethane grease boot, brake caliper and anti-lock sensor). Don’t forget the shock with a new colored boot while it is off.
21. Repeat instructions for other side.
22. Then then double check the installation and torque all bolts to Factory specifications.