



# INSTALLATION INSTRUCTIONS

Part Number 69-1005

Honda Civic SI 1999

1. Remove the stock air box and rubber intake.
2. Unplug the sensor harness and remove the vacuum hose from the stock rubber tube.
3. Insert the 10mm stub into the fitting on the intake pipe. (fig. 1)
4. Remove the radiator fluid line and intake hose connected to valve cover. (fig. 2)
5. Replace the radiator fluid line with the 8mm hose provided and 2 stock pinch clamps from the stock hose assembly. (fig. 3)
6. Assemble the saddle bracket with hardware provided. (fig. 4)
7. Using a 5/16 socket and ratchet, remove the bolt from the power steering bracket as shown. (fig. 5)
8. Install the saddle bracket assembly to the power steering bracket with the factory bolt that was removed in the previous steps. DO NOT TIGHTEN COMPLETELY AT THIS TIME. (fig. 6)
9. Slide the step hose onto the bent end of the intake tube. (fig. 7)
10. Install the #40 and #48 hose clamp on the step hose, but only tighten the #48 at this time. (fig. 7)
11. Slip step hose over the throttle body. (fig. 8)
12. With tube position in saddle bracket slide another #48 hose clamp over tube and saddle bracket.(fig. 9)
13. Using 8mm wrench tighten the #48 hose clamp around the saddle.
14. At this time completely tighten the hose clamps around the throttle body.
15. Install sensor into 10mm stub on tube. (fig. 10)
16. Using 10mm hose and stock pinch clamps install tubing from valve cover to small fitting on the tube. (fig. 11)
17. Attach filter to the end of tube with #48 hose clamp. (fig. 12)
18. The C.A.R.B. exemption sticker, (attached), must be visible under the hood, so that an emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.

## Parts List:

- 1 = Intake Tube
- 1 = 2-1/2"-3.0" Step Hose
- 1 = 12-1/2" 8mm Hose
- 1 = 10-1/2" 8mm Hose
- 1 = 3/4" 10mm hose
- 1 = #40 Clamp
- 2 = #48 Clamp
- 1 = Bracket, "L"
- 1 = Saddle Bracket
- 1 = Nut 6mm Nylock Hexhead
- 1 = Washer; Conical, Nylon, Black
- 2 = Washer 1/4" ID x 5/8" OD
- 1 = Bolt 6mm-1.00x20mm F/H/A SS
- 1 = K&N Filter

**\*WARNING:** It will be necessary for all Typhoon Intake Systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void warranty.



Fig. #1



Fig. #2



Fig. #3



Fig. #4



Fig. #5



Fig. #6



Fig. #7



Fig. #8



Fig. #9



Fig. #10



Fig. #11



Fig. #12