


S5141

2009-2018 RAM 1500, 5.7L HEMI, 3" SINGLE IN 2.25"
DUAL OUT MUFFLER REPLACEMENT
2019-2024 RAM 1500 CLASSIC 5.7L HEMI, 3" SINGLE IN
2.25" DUAL OUT MUFFLER REPLACEMENT

MBRP



ITEM	DESCRIPTION	QTY.
1	FRONT PIPE	1
2	MUFFLER ASSEMBLY	1
3	3.0" CLAMP	2
4	2.25" CLAMP	2

PLEASE READ BEFORE STARTING INSTALLATION

While MBRP has made every effort to ensure that all components of this system are of superior quality and properly packaged, it is the installer's responsibility to ensure the following before removal of the factory exhaust:

- that ALL components shown above are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the system you have purchased is appropriate for your vehicle year, model and configuration.
- that the system will not interfere with any modifications previously installed or planned.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this system to your vehicle please contact your dealer before commencing installation.

MBRP

Note: replaces factory rear exit duals muffler

Removal of stock system:



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5

1. Apply a penetrating lubricant liberally to all exhaust fasteners, hangers and rubber insulators.

2. Remove clamps from the rear of the muffler and remove the tail pipes from the muffler.

Refer to Figure 1.

3. Remove the clamp on the inlet of stock muffler and remove the muffler from the vehicle.

Refer to Figure 2.

Installation of MBRP Performance Exhaust:

1. Install the **Front Pipe** onto the factory front pipe, securing it with one of the supplied **3.0" Band Clamps**.

Refer to Figure 3.

2. Install the **Muffler Assembly** onto the **Front Pipe**, installing the hangers into the factory rubber insulators and securing it with the remaining **3.0" Clamp**.

Refer to Figure 4.

3. Reinstall the factory tail pipes into the **Muffler Assembly** outlets and secure them with the supplied **2.5" Clamps**.

Refer to Figure 5.

4. Carefully align the system. Align the edge of each band clamp with the edge of the joint it is connecting. Tighten all hardware and clamps, starting at the front and working rearward to secure the system. Check along the full length of the exhaust system to ensure there is adequate clearance for fuel lines, vent lines, brake lines, frame, bodywork, suspension and any wiring, etc. If there is any interference detected, relocate or adjust to provide adequate clearance. Ensure all clamp connections are secure and components are unable to rotate or slide. Band clamps require approximately 45 lb-ft (60 N-m) of torque. Verify clearances, system security and band clamp torque after 30-60 miles (50-100 km) of driving.

Congratulations! You are ready to begin experiencing the improved power, sound and driving experience of your

MBRP performance exhaust system. We know you will enjoy your purchase.