

SPECTRE®

Performance

Intake Installation Instructions P/N 9037 (red filter) - P/N 9037B (blue filter) P/N 9037K (black filter)

Year/Make/Model/Engine

2015-16 Ford Expedition 3.5L EcoBoost
2015-16 Lincoln Navigator 3.5L Ecoboost

NOT LEGAL FOR SALE OR USE ON ANY POLLUTION
CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR
STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.

See Spectreperformance.com for CARB status on each part for a specific vehicle



Parts List

- 1- Intake tube
- 1- Heat shield- Large
- 1-Heat shield- Small
- 1- Air filter
- 1- 6" Clamp
- 1- 3 1/2" Coupler
- 1- Velocity stack adapter
- 2- 3 1/2" Clamps
- 1- 1/2" ID grommet
- 1- 13" Rubber seal
- 1- 42" Rubber seal
- 1- 1/16" gap edge trim
- 4- M5x12 Screws
- 4- M5 Washers
- 4- M5 Nuts

Tools Required:

- 5/16" or 8mm Nut driver


For filter reorders ask at the
special order counter of your
local parts store or call:
1-909-673-9800

ask for: P/N HPR9892 (red filter)
P/N HPR9892B (blue filter)
P/N HPR9892K (black filter)




Step 1

Safety first! Before you begin the installation, make sure that the vehicle is in park (or neutral for a manual transmission) with the parking brake set. Disconnect the negative battery terminal and verify that all components that are listed are present. **Note:** This kit was designed and tested on a stock engine without any custom tuning done to the engine computer. Removing the battery cable may erase the programmed radio stations. The anti-theft code will need to be entered into some radios after the battery cable is connected. The anti-theft code can typically be found in the owner's manual or at your local dealership.




Step 2

Disconnect the electrical connector on the Intake Air Temperature (IAT) sensor.



Step 3

Loosen the clamp from the intake tube to the air box lid.




Step 4

Unclip the three hold down clips on the air box lid, lift the lid then slide it forward to clear the locking tabs. Remove the air box lid and air filter.




Step 5

Turn the IAT sensor counterclockwise and remove it from the factory intake tube. Remove the O-ring from the sensor.



Step 6

Install the supplied grommet into the intake tube, and then install the IAT sensor into the grommet.



Step 7

Assemble the heat shield with the tabs placed on the inside of the heat shield. Install the larger piece of rubber bulb seal around the top edge of the heat shield. Install the smaller piece of bulb seal around the hole in the heat shield.




Step 8

Then install the 2 small pieces of 1/16" gap seal on the bottom of the heatshield as shown.



Step 9

Install the Spectre intake tube through the bulb seal installed in the heatshield hole in the previous step. Then install the filter onto the intake tube as shown using the plastic funnel adapter and coupler and hose clamps.



Step 10

Install the heat shield, intake tube and filter assembly into the stock air box. Make sure that the tabs on the heat shield are inserted into the lower factory airbox slots. With the heat shield located into the slots, using the 2 factory clips from the airbox, clip the heat shield into position. The center clip will not be used and can be removed if desired. Reconnect the IAT sensor connector. Tighten the clamp on the stock intake tube.



Step 11

Make sure that all clamps and hardware are fully tightened. Reconnect the battery cable and start the engine and let it warm up. Shut it off and inspect the installation once more for any loose clamps, wires, or hardware. Test drive & enjoy! Your installation is now complete. Periodically check all clamps and brackets.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

NOT LEGAL FOR SALE OR USE ON ANY POLLUTION CONTROLLED MOTOR VEHICLE IN CALIFORNIA OR STATES ADOPTING CALIFORNIA EMISSION PROCEDURES.
See Spectreperformance.com for CARB status on each part for a specific vehicle

SPECTRE[®]
Performance

(909) 673-9800

www.spectreperformance.com

© 2017 SPECTRE PERFORMANCE Made in China

176229
8/28/17